

Configure an extended CIFS or NFS datastore

Published: 2020-06-08

The following procedures show you how to configure an external datastore for the ExtraHop system.

Before you begin

[Calculate the size needed for your extended datastore](#) 

To configure an extended datastore, you will complete the following steps:

- First, you mount the NFS or CIFS share where you want to store data.
- For NFS, optionally configure Kerberos authentication before you add the NFS mount.
- Finally, specify the newly added mount as the active datastore.

Add a CIFS mount

1. In the System Configuration section, click **Datastore**.
2. In the Extended Datastore Settings section, click **Configure Extended Datastore**.
3. Click **Add Mount**.
4. Click **Add CIFS Mount**.
5. On the Configure CIFS Mount page, enter the following information:

Mount Name

A name for the mount; for example, EXDS_CIFS.

Remote Share Path

The path for the share in the following format:

```
\\host\mountpoint
```

For example:

```
\\herring\extended-datastore
```

SMB Version

The SMB version that is compatible with your file server.

Domain

The site domain.

6. If password protection is required, complete the following steps:
 - a) From the Authentication drop-down menu, select **password**.
 - b) In the User and Password fields, type a valid username and password.
7. Click **Save**.

(Optional) Configure Kerberos for NFS

You must configure any desired Kerberos authentication before you add an NFS mount.

1. In the System Configuration section, click **Datastore and Customizations**.
2. In the Extended Datastore Settings section, click **Configure Extended Datastore**.
3. Click **Add Kerberos Config**, then complete the following information.
 - a) In the Admin Server field, type the IP address or hostname of the master Kerberos server that issues tickets.

- b) In the Key Distribution Center (KDC) field, type the IP address or hostname of the server that holds the keys.
- c) In the Realm field, type the name of the Kerberos realm for your configuration.
- d) In the Domain field, type the name of the Kerberos domain for your configuration.
4. In the Keytab File section, click **Choose File**, select a saved keytab file, and then click **Open**.
5. Click **Upload**.

Add an NFS mount

Before you begin

- Configure any applicable Kerberos authentication before you add an NFS mount.
 - Either allow read/write access for all users on the share or assign the 'extrahop' user as the owner of the share and allow read/write access.
 - You must have NFS version 4.
1. In the System Configuration section, click **Datastore and Customizations**.
 2. In the Extended Datastore Settings section, click **Configure Extended Datastore**.
 3. Click **Add NFSv4 Mount**.
 4. On the Configure NFSv4 Mount page, complete the following information:
 - a) In the Mount Name field, type a name for the mount, such as EXDS.
 - b) In the Remote Share Point field, type the path for the mount in the following format: `host : /mountpoint`, such as `herring : /mnt/extended-datastore`.
 5. From the Authentication drop-down, select from the following options:
 - **None**, For no authentication
 - **Kerberos**, For krb5 security.
 - **Kerberos (Secure Auth and Data Integrity)**, for krb5i security.
 - **Kerberos (Secure Auth, Data Integrity, Privacy)**, for krb5p security
 6. Click **Save**.

Specify a mount as an active extended datastore


After you add a CIFS or NFS mount, set the mount as your active extended datastore. Remember that only one datastore can collect metrics at a time.



Note: If you decide to store 5-minute and 1-hour metrics on the extended datastore, this option causes the appliance to migrate any 5-minute and 1-hour metrics that the appliance collected from the local ExtraHop system datastore to the extended datastore. Migrating 5-minute and 1-hour metrics to an extended datastore leaves more room to store 30-second metrics on the local datastore, which increases the amount of high-resolution lookback available.


1. In the System Configuration section, click **Datastore and Customizations**.
2. In the Extended Datastore Settings section, click **Configure Extended Datastore**.
3. From the Mount Name drop-down, select the name of the mount you want to specify as the extended datastore.
4. In the Datastore Directory field, type a name for the datastore directory. The directory is automatically created on the mount point by the ExtraHop system.
5. From the Configure as options, select the **Active** radio button.
6. In the Datastore Size field, specify the maximum amount of data that can be stored on the datastore.

7. Select the checkbox to store 5-minute and 1-hour metrics on the extended datastore. 24-hour metrics are always stored on the extended datastore.
8. Specify whether to migrate existing metrics to the extended datastore by selecting from one of the following options.
 - To migrate existing metrics, click **Move existing metrics to the extended datastore**.
 - To retain existing metrics on the local datastore, click **Keep existing metrics on the ExtraHop**.

 **Warning:** While data is migrated, the ExtraHop system stops collecting data and system performance is degraded. The migration process takes more time under the following circumstances:

 - If there is a large amount of data to migrate
 - If the network connection to the NAS device hosting the datastore is slow
 - If the write performance of the NAS device hosting the datastore is slow
9. Select **Move existing**.
10. Specify what the system should do if the datastore becomes full by selecting from the following options.
 - To overwrite older data when the datastore becomes full, click **Overwrite**.
 - To stop storing new metrics on the extended datastore when the datastore becomes full, click **Stop writing**.
11. Click **Configure**.
12. After the storage is added, the Status displays `Nominal`.

Next steps

- [Troubleshoot issues with an extended datastore](#) 
- [Archive an extended datastore for read-only access](#) 