

Configure the iDRAC Remote Access Console

Published: 2024-04-01

If your ExtraHop system is deployed in a data center or other remote environment, you might need to access the console and power-management features through a remote connection. Remote access is available on the ExtraHop system through the Integrated Dell Remote Access Controller (iDRAC). After you enable and configure iDRAC, you can power cycle the system, view console messages, and review hardware monitoring and boot logs.

The iDRAC interface is enabled by default on all ExtraHop appliances, except the EDA 1100 and EDA 1200, which do not have an iDRAC interface. You can download updates for the iDRAC controller firmware from the [Dell Technologies website](#).



Note: The steps and menu options to change settings can vary by iDRAC version.

Accessing the iDRAC

1. When the appliance is running, the LCD displays the existing IP address. Under the LCD, press the checkmark button between the two arrows.
2. Highlight **iDRAC** and press the checkmark button.




3. Highlight **IP** and press the checkmark button.



4. Write down the IP address that appears on the LCD.



5. In a web browser, type the IP address, and log in with the username `root` and the password, which is the service tag number listed in the screen or on the pullout at the front of the appliance. The password is case-sensitive.



Integrated Remote Access Controller 9

14G-6200-01 | EDA 6200 Discover Appliance | Enterprise

Type the User Name and Password and click Log In.

Username:

Password:


Domain:

Security Notice: By accessing this computer, you confirm that such access complies with your organization's security policy.

Configuring the iDRAC with a static IP address

1. Click **iDRAC Settings**.
2. In the Current IPv4 Settings section, click **Configure IPv4 Settings**.
3. Select **Disabled** from the DHCP drop-down menu.
4. In the **Static IP Address** field, type the IP address that you want to configure for remote access to your ExtraHop system.

IPv4 Settings



Enabled IPv4

DHCP

Static IP Address*

Static Gateway*

Static Subnet Mask*

Use DHCP to Obtain DNS Server Addresses


Static Preferred DNS Server

Static Alternate DNS Server

Launching the iDRAC virtual console

1. From the **Configuration** menu, click **Virtual Console**.


2. Click **Launch Virtual Console**.



Power cycling the system

1. From the **Configuration** menu, select **Power Management**.
2. From the **Power Control** drop-down menu, select **Reset System (warm reboot)**.

Configuration




3. Click **Apply**.

Set a secure password

The iDRAC password is configured by default with the service tag number on the pullout at the front of the ExtraHop appliance. You should change the default password to a more secure password that you choose.


1. From the **iDRAC Settings** menu, click **Users**.
2. Click **Local Users**.
3. Select the root user and then click **Edit**.
4. Type the new password, and then type the password again to confirm.


 **Important:** Passwords cannot contain more than 20 characters.

5. Click **Save**.

Update the iDRAC firmware

To take advantage of iDRAC firmware enhancements, you can update the iDRAC controller firmware. The iDRAC controller firmware is not updated when you upgrade the ExtraHop system firmware.

 **Important:** This procedure requires that you shut down the appliance to complete the update process.

1. Follow the instructions on the [Dell Technologies website](#)  to update the firmware.
2. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
3. In the Appliance Settings section, click **Shutdown or Restart**, and then click **Shutdown**.
4. Log in to the iDRAC web interface.
5. On the Dashboard page, select **Power On System**.