



ExtraHop 9.9

ExtraHop Trace Admin UI Guide

© 2025ExtraHop Networks, Inc. All rights reserved.

This manual in whole or in part, may not be reproduced, translated, or reduced to any machine-readable form without prior written approval from ExtraHop Networks, Inc.

For more documentation, see <https://docs.extrahop.com>.

Published: 2025-03-11

ExtraHop Networks
Seattle, WA 98101
877-333-9872 (US)
+44 (0)203 7016850 (EMEA)
+65-31585513 (APAC)
www.extrahop.com

Contents

Introduction to the ExtraHop Trace Admin UI	6
Supported browsers	6
Status and Diagnostics	7
Health	7
Audit Log	8
Fingerprint	8
Support Scripts	9
Run the default support script	9
Run a custom support script	9
Exception Files	9
Network Settings	10
Connect to ExtraHop Cloud Services	10
Configure your firewall rules	11
Connect to ExtraHop Cloud Services through a proxy	12
Bypass certificate validation	13
Disconnect from ExtraHop Cloud Services	13
Manage ExtraHop Cloud Services enrollment	13
Connectivity	13
Configure an interface	14
Interface throughput	16
Set a static route	16
Enable IPv6 for an interface	17
Global proxy server	17
ExtraHop Cloud proxy	17
Bond interfaces	17
Create a bond interface	18
Modify bond interface settings	18
Destroy a bond interface	19
Notifications	19
Configure email settings for notifications	19
Add a new notification email address on an Explore or Trace appliance	20
Configure settings to send notifications to an SNMP manager	21
Download the ExtraHop SNMP MIB	21
Send system notifications to a remote syslog server	21
TLS Certificate	23
Upload a TLS certificate	23
Generate a self-signed certificate	23
Create a certificate signing request from your ExtraHop system	24
Trusted Certificates	25
Add a trusted certificate to your ExtraHop system	25
Access Settings	26
Passwords	26
Change the default password for the setup user	26
Support Access	26
Generate SSH key	26
Regenerate or revoke the SSH key	27

Users	27
Users	27
Local users	27
Add a local user account	27
Remote Authentication	28
Remote users	28
Sessions	29
Remote Authentication	29
Configure remote authentication through LDAP	29
Configure user privileges for remote authentication	31
Configure remote authentication through RADIUS	33
Configure remote authentication through TACACS+	34
Configure the TACACS+ server	35
API Access	37
Manage API key access	37
Configure cross-origin resource sharing (CORS)	37
Generate an API key	38
Privilege levels	38

Appliance Settings 42

Running Config	42
Save system settings to the running configuration file	42
Edit the running configuration file	43
Download the running configuration as a text file	43
Disable ICMPv6 Destination Unreachable messages	43
Disable specific ICMPv6 Echo Reply messages	43
Services	44
SNMP Service	44
Firmware	44
Upgrade the firmware on your ExtraHop system	45
Pre-upgrade checklist	45
Upgrade the firmware on a console and sensor	46
Upgrade the firmware on recordstores	46
Upgrade the firmware on packetstores	47
Upgrade connected sensors in RevealX 360	47
System Time	48
Configure the system time	49
Shutdown or restart	49
License	50
Register your ExtraHop system	50
Register the appliance	50
Troubleshoot license server connectivity	51
Apply an updated license	51
Update a license	51
Disks	52
Encrypt the packetstore disk	53
Change the packet capture disk encryption key	53
Add storage capacity to an ExtraHop packetstore	54
Managing extended storage units with a foreign packetstore status	54
For extended storage units disconnected and then reconnected to the same Trace appliance	54
For extended storage units configured on a device other than the Trace appliance	54
Reset Packetstore	54

Trace Cluster Settings	55
Manager	55
Packet Query Status	55
Remove packet queries	56
Manage with a console	56

Introduction to the ExtraHop Trace Admin UI

The ExtraHop Trace Admin UI Guide provides detailed information about the administrator features and functionality of the ExtraHop Trace appliance.

In addition, this guide provides an overview of the global navigation and information about the controls, fields, and options available throughout the Trace Administration settings.


After you have deployed your Trace appliance, see the [Trace Post-deployment Checklist](#).

We value your feedback. Please let us know how we can improve this document. Send your comments or suggestions to documentation@extrahop.com.

Supported browsers

The following browsers are compatible with all ExtraHop systems. Apply the accessibility and compatibility features provided by your browser to access content through assistive technology tools.

- Firefox
- Google Chrome
- Microsoft Edge
- Safari

 **Important:** Internet Explorer 11 is no longer supported. We recommend that you install the latest version of any supported browser.

Status and Diagnostics

The Status and Diagnostics section includes metrics and logging data about the current state of the ExtraHop packetstore and enables system administrators to view the overall system health.

Health

Provides metrics about the operating efficiency of the ExtraHop packetstore.

Audit Log

Enables you to view event logging data and to change syslog settings.

Fingerprint

Provides the unique hardware fingerprint for the ExtraHop packetstore.

Support Scripts

Enables you to upload and run support scripts.

Exception Files

Enable or disable the ExtraHop packetstore exception files.

Health

The Health page provides a collection of metrics that enable you check the operation of the Trace appliance.

The metrics on this page can help you troubleshoot problems and determine why the ExtraHop appliance is not performing as expected.

System

Reports the following information about the system CPU usage and disk drives.

CPU User

Displays the percentage of CPU usage associated with the Trace appliance user.

CPU System

Displays the percentage of CPU usage associated with the Trace appliance.

CPU Idle

Displays the CPU idle percentage associated with the Trace appliance.

CPU IO

Displays the percentage of CPU usage associated with the Trace appliance IO functions.

Service Status

Reports the status of ExtraHop packetstore system services.

exadmin

Displays the time the ExtraHop packetstore web portal service started.

exconfig

Displays the time the ExtraHop packetstore config service started.

excap

Displays the time the ExtraHop packetstore capture service started.

Interfaces

Reports the status of ExtraHop packetstore network interfaces.

RX packets

Displays the number of packets received by the ExtraHop packetstore on the specified interface.

RX Errors

Displays the number of received packet errors on the specified interface.

RX Drops

Displays the number of received packets dropped on the specified interface.

TX Packets

Displays the number of packets transmitted by the ExtraHop packetstore on the specified interface.

TX Errors

Displays the number of transmitted packet errors on the specified interface.

TX Drops

Displays the number of transmitted packets dropped on the specified interface.

RX Bytes

Displays the number of bytes received by the ExtraHop packetstore on the specified interface.

TX Bytes

Displays the number of bytes transmitted by the ExtraHop packetstore on the specified interface.

Partitions

Reports the status and usage of ExtraHop packetstore components. The configuration settings for these components are stored on disk and retained even when the power to the packetstore is turned off.

Name

Displays the ExtraHop packetstore settings that are stored on disk.

Options

Displays the read-write options for the settings stored on disk.

Size

Displays the size in gigabytes for the identified component.

Utilization

Displays the amount of memory usage for each of the components as a quantity and as percentage of total disk space.

Audit Log

The audit log provides data about the operations of your ExtraHop system, broken down by component. The audit log lists all known events by timestamp, in reverse chronological order.

If you experience an issue with the ExtraHop system, consult the audit log to view detailed diagnostic data to determine what might have caused the issue.

Fingerprint

Fingerprints help secure appliances from machine-in-the-middle attacks by providing a unique identifier that can be verified when connecting ExtraHop appliances.

When connecting an ExtraHop recordstore or packetstore with a packet sensor or console, make sure that the fingerprint displayed is exactly the same as the fingerprint shown on the join or pairing page.

If the fingerprints do not match, communications between the devices might have been intercepted and altered.

Support Scripts

ExtraHop Support might provide a support script that can apply a special setting, make a small adjustment to the ExtraHop system, or provide help with remote support or enhanced settings. The Administration settings enable you to upload and run support scripts.

Run the default support script

The default support script gathers information about the state of the ExtraHop system for analysis by ExtraHop Support.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Status and Diagnostics section, click **Support Scripts**.
3. Click **Run Default Support Script**.
4. Click **Run**.

When the script completes, the Support Script Results page appears.

5. Click the name of the diagnostic support package that you want to download.

The file saves to the default download location on your computer.

Send this file, typically named `diag-results-complete.expk`, to ExtraHop Support.

The `.expk` file is encrypted and the contents are only viewable by ExtraHop Support. However, you can download the `diag-results-complete.manifest` file to view a list of the files collected.

Run a custom support script

If you receive a custom support script from ExtraHop Support complete the following procedure to make a small adjustment to the system or apply enhanced settings.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Status and Diagnostics section, click **Support Scripts**.
3. Click **Run Custom Support Script**.
4. Click **Choose File**, navigate to the diagnostic support script you want to upload, and then click **Open**.
5. Click **Upload** to run the file on the ExtraHop system.

ExtraHop Support will confirm that the support script achieved the desired results.

Exception Files

Exception files are a core file of the data stored in memory. When you enable the Exception File setting, the core file is written to the disk if the system unexpectedly stops or restarts. This file can help ExtraHop Support diagnose the issue.

Click **Enable Exception Files** or **Disable Exception Files** to enable or disable the saving of exception files.

Network Settings

The Network Settings section provides the following configurable network connectivity settings.

Connectivity

Configure network connections.

SSL Certificate

Generate and upload a self-signed certificate.

Notifications

Set up alert notifications through email and SNMP traps.

The Trace appliance has two 10/100/1000baseT network ports and four 10 GbE SFP+ network ports. By default, the Gb3 port is configured as the management port and requires an IP address. Port 5 is the default monitor (or capture) interface.

Before you begin configuring the network settings, verify that a network patch cable connects the Gb3 port on the Trace appliance to the management network. For more information about installing a Trace appliance, see the [ExtraHop Trace appliance deployment guide](#) or contact [ExtraHop Support](#) for assistance.

For specifications, installation guides, and more information about your appliance, see the complete ExtraHop documentation set at docs.extrahop.com.

Connect to ExtraHop Cloud Services

ExtraHop Cloud Services provides access to ExtraHop cloud-based services through an encrypted connection.

Your system license determines which services are available for your ExtraHop console or sensor. A single license can only be applied to a single appliance or virtual machine (VM) at a time. If you want to repurpose a license from one appliance or VM to another, you can [manage system enrollment](#) from the ExtraHop Cloud Services page.

After the connection is established, information about the available services appear on the ExtraHop Cloud Services page.

- By sharing data with ExtraHop Machine Learning Service, you can enable features that enhance the ExtraHop system and your user experience.
 - Enable AI Search Assistant to find devices with natural language user prompts, which are shared with ExtraHop Cloud Services for product improvement. See the [AI Search Assistant FAQ](#) for more information.
 - Opt in to Expanded Threat Intelligence to enable the Machine Learning Service to review data such as IP addresses and hostnames against threat intelligence provided by CrowdStrike, benign endpoints, and other network traffic information. See the [Expanded Threat Intelligence FAQ](#) for more information.
 - Contribute data such as file hashes and external IP addresses to Collective Threat Analysis to improve the accuracy of detections. See the [Collective Threat Analysis FAQ](#) for more information.
- ExtraHop Update Service enables automatic updates of resources to the ExtraHop system, such as ransomware packages.
- ExtraHop Remote Access enables you to allow ExtraHop account team members and ExtraHop Support to connect to your ExtraHop system for configuration help. See the [Remote Access FAQ](#) for more information about remote access users.



View the related training: [Connect to ExtraHop Cloud Services](#)

Before you begin

- RevealX 360 systems are automatically connected to ExtraHop Cloud Services, however, you might need to **allow access through network firewalls**.
 - You must apply the relevant license on the ExtraHop system before you can connect to ExtraHop Cloud Services. See the [License FAQ](#) for more information.
 - You must have setup or **system and access administration privileges** to access Administration settings.
1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
 2. In the Network Settings section, click **ExtraHop Cloud Services**.
 3. Click **Terms and Conditions** to read the content.
 4. Read the terms and conditions, and then select the checkbox.
 5. Click **Connect to ExtraHop Cloud Services**.
After you are connected, the page updates to show status and connection information for each service.
 6. (Optional) In the Machine Learning Service section, select one or more enhanced features:
 - Enable AI Search Assistant by selecting **I agree to enable AI search assistant and send natural language searches to ExtraHop Cloud Services**. (NDR module required)
 - Enable Expanded Threat Intelligence by selecting **I agree to send IP addresses, domain names, hostnames, file hashes, and URLs to ExtraHop Cloud Services**.
 - Enable Collective Threat Analysis by selecting **I agree to contribute domain names, hostnames, file hashes, and external IP addresses to ExtraHop Cloud Services**.

If the connection fails, there might be an issue with your firewall rules.

Configure your firewall rules

If your ExtraHop system is deployed in an environment with a firewall, you must open access to ExtraHop Cloud Services. For RevealX 360 systems that are connected to sensors, you must also open access to the cloud-based recordstore included with RevealX Standard Investigation

Open access to Cloud Services

For access to ExtraHop Cloud Services, your sensors must be able to resolve DNS queries for *.extrahop.com and have access to TCP 443 (HTTPS) from one of the following IP addresses that correspond to your sensor license. We recommend opening access to both IP addresses to avoid service interruption.

Region	IP Addresses
North, Central, South America (AMER)	35.161.154.247
	54.191.189.22
Asia, Pacific (APAC)	54.66.242.25
	13.239.224.80
Europe, Middle East, Africa (EMEA)	52.59.110.168
	18.198.13.99
United States Federal (US-FED)	3.135.6.11
	3.139.111.240

Open access to RevealX 360 Premium Investigation

For access to RevealX 360 Premium Investigation, your sensors must meet the following requirements:

- Sensors must be running ExtraHop firmware version 9.9 or later.
- Sensors must be able to access specific fully-qualified domain names over outbound TCP 443 (HTTPS).
- Sensors located in the United States must be able to access these domain names:
 - `eh.oem-2-1.logscale.us-2.crowdstrike.com`
 - `eh.oem-2-2.logscale.us-2.crowdstrike.com`
- Sensors located in the European Union must be able to access this domain name:
 - `eh.oem-2-3.logscale.eu-1.crowdstrike.com`

In addition to configuring access to these domains, you must also configure the [global proxy server settings](#).

Open access to RevealX 360 Standard Investigation

For access to RevealX 360 Standard Investigation, your sensors must be able to access outbound TCP 443 (HTTPS) to these fully-qualified domain names:

- `bigquery.googleapis.com`
- `bigquerystorage.googleapis.com`
- `oauth2.googleapis.com`
- `www.googleapis.com`
- `www.mtls.googleapis.com`
- `iamcredentials.googleapis.com`

You can also review the public guidance from Google about [computing possible IP address ranges](#) for `googleapis.com`.


In addition to configuring access to these domains, you can also configure the [global proxy server settings](#).

Connect to ExtraHop Cloud Services through a proxy

If you do not have a direct internet connection, you can try connecting to ExtraHop Cloud Services through an explicit proxy. The ExtraHop system will also communicate with the ExtraHop license server through the proxy connection.

Before you begin

Verify whether your proxy vendor is configured to perform machine-in-the-middle (MITM) when tunneling SSH over HTTP CONNECT to `localhost:22`. ExtraHop Cloud Services deploys an encrypted inner SSH tunnel, so traffic will not be visible to MITM inspection. We recommend that you create a security exception and disable MITM inspection for this traffic.

 **Important:** If you are unable to disable MITM on your proxy, you must disable certificate validation in the ExtraHop system running configuration file. For more information, see [Bypass certificate validation](#).

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. Click **Enable ExtraHop Cloud Proxy**.
4. In the Hostname field, type the hostname for your proxy server, such as `proxyhost`.
5. In the Port field, type the port for your proxy server, such as `8080`.
6. (Optional) If required, in the Username and Password fields, type a user name and password for your proxy server.
7. Click **Save**.

Bypass certificate validation

Some environments are configured so that encrypted traffic cannot leave the network without inspection by a third-party device. This device can act as an TLS endpoint that decrypts and re-encrypts the traffic before sending the packets to ExtraHop Cloud Services.

If a system is connecting to ExtraHop Cloud Services through a proxy server and the certificate validation fails, disable certificate validation and attempt the connection again. The security provided by ExtraHop system authentication and encryption ensures that communication between systems and ExtraHop Cloud services cannot be intercepted.



Note: The following procedure requires familiarity with modifying the ExtraHop running configuration file.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **Running Config**.
3. Click **Edit config**.
4. Add the following line to the end of the running configuration file:

```
"hopcloud": { "verify_outer_tunnel_cert": false }
```

5. Click **Update**.
6. Click **View and Save Changes**.
7. Review the changes.
8. Click **Save**.
9. Click **Done**.

Disconnect from ExtraHop Cloud Services

You can disconnect an ExtraHop system from ExtraHop Cloud Services.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **ExtraHop Cloud Services**.
3. In the Cloud Services Connection section, click **Disconnect**.

Manage ExtraHop Cloud Services enrollment

Before you begin

Your system license determines which services are available for your ExtraHop console or sensor. A single license can only be applied to a single appliance or virtual machine (VM) at a time. If you want to repurpose a license from one appliance or VM to another, you can manage system enrollment from the ExtraHop Cloud Services page.

Unenrolling a system deletes all data and historical analysis for the Machine Learning Service from the system and will no longer be available.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **ExtraHop Cloud Services**.
3. In the Cloud Services Connection section, click **Unenroll**.

Connectivity

The Connectivity page contains controls for your appliance connections and network settings.

Interface Status

On physical appliances, a diagram of interface connections appears, which updates dynamically based on the port status.

- The blue Ethernet port is for management
- A black Ethernet port indicates a licensed and enabled port that is currently down
- A green Ethernet port indicates an active, connected port
- A gray Ethernet port indicates a disabled or unlicensed port

Network Settings

- Click **Change Settings** to add a hostname for your ExtraHop appliance or to add DNS servers.

Proxy Settings

- Enable a **global proxy** to connect to an ExtraHop console
- Enable a **cloud proxy** to connect to ExtraHop Cloud Services

Bond Interface Settings

- Create a **bond interface** to bond multiple interfaces together into one logical interface with a single IP address.

Interfaces

View and configure your management and monitoring interfaces. Click any interface to display setting options.

- [Collect traffic from NetFlow and sFlow devices](#)
- [Packet Forwarding with RPCAP](#)

Packet Ingest Settings

- [Configure the source of packets ingested by this sensor](#). You can enable the sensor to ingest packets from a direct feed or packets forwarded from a third-party.

Configure an interface

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. In the Interfaces section, click the name of the interface you want to configure.
4. On the Network Settings for Interface *<interface number>* page, from the **Interface Mode** drop-down menu, select one of the following options:

Disabled

The interface is disabled.

Monitoring (receive only)

Monitors network traffic.

Management

Manages the ExtraHop sensor.

Management + RPCAP/ERSPAN/VXLAN/GENEVE Target

Manages the ExtraHop sensor and captures traffic forwarded from a packet forwarder, ERSPAN*, VXLAN**, or GENEVE***.

While 10 GbE management + capture interfaces on this sensor can conduct management functions at 10 Gbps speeds, processing traffic such as ERSPAN, VXLAN, and GENEVE is limited to 1 Gbps.



Tip: In environments with asymmetric routing adjacent to the high-performance interfaces, ping replies might not get back to the sender.

High-Performance ERSPAN/VXLAN/GENEVE Target

Captures traffic forwarded from ERSPAN *, VXLAN**, or GENEVE***. This interface mode enables the port to handle more than 1 Gbps. Set this interface mode if the ExtraHop sensor has a 10 GbE port. This interface mode only requires that you configure an IPv4 address.

* The ExtraHop system supports the following ERSPAN implementations:

- ERSPAN Type I
- ERSPAN Type II
- ERSPAN Type III
- Transparent Ethernet Bridging. ERSPAN-like encapsulation commonly found in virtual switch implementations such as the VMware VDS and Open vSwitch.

**Virtual Extensible LAN (VXLAN) packets are received on UDP port 4789.

***Generic Network Virtualization Encapsulation (GENEVE) packets are received on UDP port 6081. To configure GENEVE-encapsulated traffic forwarded from an AWS Gateway Load Balancer (GWLB) acting as a VPC Traffic Mirroring target, see the [AWS documentation](#).



Note: For Amazon Web Services (AWS) deployments with one interface, you must select **Management + RPCAP/ERSPAN/VXLAN/GENEVE Target** for Interface 1. If you are configuring two interfaces, you must select **Management + RPCAP/ERSPAN/VXLAN/GENEVE Target** for Interface 1 and **Management + RPCAP/ERSPAN/VXLAN/GENEVE Target** for Interface 2.



Note: For Azure deployments, some instances running older NICs might not support High-Performance ERSPAN/VXLAN/GENEVE Target mode.

5. (Optional) Select an interface speed.

Auto-negotiate is selected by default; however, you should manually select a speed if it is supported on your sensor, network transceiver, and network switch.

- **Auto-negotiate**
- **10 Gbps**
- **25 Gbps**
- **40 Gbps**
- **100 Gbps**



Important: When you change the interface speed to **Auto-negotiate**, you might need to restart the sensor before the change takes effect.

6. (Optional) Select a forward error correction (FEC) type.

We recommend Auto-negotiate, which is optimal for most environments.

- **Auto-negotiate:** Automatically enables either RS-FEC or Firecode FEC or disables FEC based on the capabilities of connected interfaces.
- **RS-FEC:** Always enables Reed-Solomon FEC.
- **Firecode:** Always enables Firecode (FC) FEC, also known as BaseR FEC.
- **Disabled:** Disables FEC.

7. Configure DHCP.

DHCPv4 is enabled by default. If your network does not support DHCP, you can clear the **DHCPv4** checkbox to disable DHCP and then type a static IP address, netmask, and default gateway.



Note: Only one interface should be configured with a default gateway. [Configure static routes](#) if your network requires routing through multiple gateways.

8. Configure the TCP health check port.

This setting is only configurable on high-performance interfaces and is required when ingesting GENEVE traffic from an AWS Gateway Load Balancer (GWLB). The port number value must match the

value configured in AWS. For more information, see [Forward GENEVE-encapsulated traffic from an AWS Gateway Load Balancer](#).

9. (Optional) Enable IPv6.

For more information about configuring IPv6, see [Enable IPv6 for an interface](#).

10. (Optional) Manually add routes.

11. Click **Save**.

Interface throughput

ExtraHop sensor models EDA 6100, EDA 8100, and EDA 9100 are optimized to capture traffic exclusively on 10GbE ports.

Enabling the 1GbE interfaces for monitoring traffic can impact performance, depending on the ExtraHop sensor. While you can optimize these sensors to capture traffic simultaneously on both the 10GbE ports and the three non-management 1GbE ports, we recommend that you contact ExtraHop Support for assistance to avoid reduced throughput.



Note: EDA 6200, EDA 8200, EDA 9200, and EDA 10200 sensors are not susceptible to reduced throughput if you enable 1GbE interfaces for monitoring traffic.

ExtraHop Sensor	Throughput	Details
EDA 9100	Standard 40Gbps throughput	If the non-management 1GbE interfaces are disabled, you can use up to four of the 10GbE interfaces for a combined throughput of up to 40Gbps.
EDA 8100	Standard 20Gbps throughput	If the non-management 1GbE interfaces are disabled, you can use either one or both of the 10GbE interfaces for a combined throughput of up to 20Gbps.
EDA 6100	Standard 10Gbps throughput	If the non-management 1GbE interfaces are disabled, the maximum total combined throughput is 10Gbps.
EDA 3100	Standard 3Gbps throughput	No 10GbE interface
EDA 1100	Standard 1Gbps throughput	No 10GbE interface

Set a static route

Before you begin

You must disable DHCPv4 before you can add a static route.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. In the Interfaces section, click the name of the interface you want to configure.
4. On the Network Settings for Interface <interface number> page, ensure that the **IPv4 Address** and **Netmask** fields are complete and saved, and click **Edit Routes**.
5. In the Add Route section, type a network address range in CIDR notation in the **Network** field and IPv4 address in the **Via IP** field and then click **Add**.
6. Repeat the previous step for each route you want to add.
7. Click **Save**.

Enable IPv6 for an interface

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. In the Interfaces section, click the name of the interface you want to configure.
4. On the Network Settings for Interface *<interface number>* page, select **Enable IPv6**. IPv6 configuration options appear below **Enable IPv6**.
5. (Optional) Configure IPv6 addresses for the interface.
 - To automatically assign IPv6 addresses through DHCPv6, select **Enable DHCPv6**.



Note: If enabled, DHCPv6 will be used to configure DNS settings.

- To automatically assign IPv6 addresses through stateless address autoconfiguration, from the **Stateless Address Autoconfiguration** drop-down menu, select one of the following options:
 - Use MAC address**
Configures the appliance to automatically assign IPv6 addresses based on the MAC address of the appliance.
 - Use stable private address**
Configures the appliance to automatically assign private IPv6 addresses that are not based on hardware addresses. This method is described in RFC 7217.
 - To manually assign one or more static IPv6 addresses, type the addresses in the Static IPv6 Addresses field.
6. To enable the appliance to configure Recursive DNS Server (RDNSS) and DNS Search List (DNSSL) information according to router advertisements, select **RDNSS/DNSSL**.
 7. Click **Save**.

Global proxy server

If your network topology requires a proxy server to enable your ExtraHop system to communicate either with a console or with other devices outside of the local network, you can enable your ExtraHop system to connect to a proxy server you already have on your network. Internet connectivity is not required for the global proxy server.

ExtraHop Cloud proxy

If your ExtraHop system does not have a direct internet connection, you can connect to the internet through a proxy server specifically designated for ExtraHop Cloud services connectivity. Only one proxy can be configured per system.

Complete the following fields and click **Save** to enable a cloud proxy.


- **Hostname:** The hostname or IP address for your cloud proxy server.
- **Port:** The port number for your cloud proxy server.
- **Username:** The name of a user that has for access to your cloud proxy server.
- **Password:** The password for the user specified above.

Bond interfaces

You can bond multiple interfaces on your ExtraHop system together into a single logical interface that has one IP address for the combined bandwidth of the member interfaces. Bonding interfaces enable a larger throughput with a single IP address. This configuration is also known as link aggregation, port channeling, link bundling, Ethernet/network/NIC bonding, or NIC teaming. Bond interfaces cannot be set to monitoring mode.



Note: When you modify bond interface settings, you lose connectivity to your ExtraHop system. You must make changes to your network switch configuration to restore connectivity. The changes required are dependent on your switch. Contact ExtraHop Support for assistance before you create a bond interface.

- Bonding is only configurable on Management or Management + interfaces.
- **Port channeling**  on traffic monitoring ports is supported on the ExtraHop sensors.

Interfaces chosen as members of a bond interface are no longer independently configurable and are shown as Disabled (bond member) in the Interfaces section of the Connectivity page. After a bond interface is created, you cannot add more members or delete existing members. The bond interface must be destroyed and recreated.

- [Create a bond interface](#)
- [Modify a bond interface](#)
- [Destroy a bond interface](#)

Create a bond interface

You can create a bond interface with at least one interface member and up to the number of members that are available for bonding.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. In the Bond Interface Settings section, click **Create Bond Interface**.
4. Select the checkbox next to each interface you want to include in the bonding.
Only ports that are currently available for bond membership appear.
5. From the **Take Settings From** drop-down menu, select the interface that has the settings you want to apply to the bond interface.
Settings for all non-selected interfaces will be lost.
6. For **Bond Type**, select one of the following options:
 - **Static**, which creates a static bond.
 - **802.3ad (LACP)**, which creates a dynamic bond through IEEE 802.3ad Link Aggregation (LACP).
7. From the **Hash Policy** drop-down menu, select one of the following options:
 - **Layer 3+4** policy, which balances the distribution of traffic more evenly across interfaces; however, this policy is not fully compliant with 802.3ad standards.
 - **Layer 2+3** policy, which balances traffic less evenly and is compliant with 802.3ad standards.
8. Click **Create**.

Refresh the page to display the Bond Interfaces section. Any bond interface member whose settings were not selected in the **Take Settings From** drop-down menu are shown as **Disabled (bond member)** in the Interfaces section.

Modify bond interface settings

After a bond interface is created, you can modify most settings as if the bond interface is a single interface.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. In the Bond Interfaces section, click the bond interface you want to modify.
4. On the Network Settings for Bond Interface *<interface number>* page, modify the following settings as needed:

- **Members:** The interface members of the bond interface. Members cannot be changed after a bond interface is created. If you need to change the members, you must destroy and recreate the bond interface.
- **Bond Mode:** Specify whether to create a static bond or a dynamic bond through IEEE 802.3ad Link Aggregation (LACP).
- **Interface Mode:** The mode of the bond membership. A bond interface can be **Management** or **Management+RPCAP/ERSPAN Target** only.
- **Enable DHCPv4:** If DHCP is enabled, an IP address for the bond interface is automatically obtained.
- **Hash Policy:** Specify the hash policy. The **Layer 3+4** policy balances the distribution of traffic more evenly across interfaces; however, it is not fully compliant with 802.3ad standards. The **Layer 2+3** policy balances traffic less evenly; however, it is compliant with 802.3ad standards.
- **IPv4 Address:** The static IP address of the bond interface. This setting is unavailable if DHCP is enabled.
- **Netmask:** The network netmask for the bond interface.
- **Gateway:** The IP address of the network gateway.
- **Routes:** The static routes for the bond interface. This setting is unavailable if DHCP is enabled.
- **Enable IPv6:** Enable configuration options for IPv6.

5. Click **Save**.

Destroy a bond interface

When a bond interface is destroyed, the separate interface members of the bond interface return to independent interface functionality. One member interface is selected to retain the interface settings for the bond interface and all other member interfaces are disabled. If no member interface is selected to retain the settings, the settings are lost and all member interfaces are disabled.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Connectivity**.
3. In the Bond Interfaces section, click the red **X** next to the interface you want to destroy.
4. On the Destroy Bond Interface *<interface number>* page, select the member interface to which you want to move the bond interface settings.
Only the member interface selected to retain the bond interface settings remains active, and all other member interfaces are disabled.
5. Click **Destroy**.

Notifications

The ExtraHop system can send notifications about configured alerts through email, SNMP traps, and syslog exports to remote servers. If an email notification group is specified, then emails are sent to the groups assigned to the alert.

Configure email settings for notifications

You must configure an email server and sender before the ExtraHop system can send alert notifications, System Health notifications, or scheduled reports.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Notifications**.
3. Click **Email Server and Sender**.
4. In the SMTP Server field, type the IP address or hostname for the outgoing SMTP mail server.

The SMTP server is the fully qualified domain name (FQDN) or IP address of an outgoing mail server that is accessible from the ExtraHop system. If the DNS server is set, then the SMTP server can be a FQDN, otherwise you must type an IP address.

5. In the SMTP Port field, type the port number for SMTP communication.
Port 25 is the default value for SMTP, and port 465 is the default value for TLS encrypted SMTP.
6. From the Encryption drop-down menu, select one of the following encryption methods:

None

SMTP communication is not encrypted.

TLS

SMTP communication is encrypted through the Secure Socket Layer/Transport Layer Security protocol.

STARTTLS

SMTP communication is encrypted through STARTTLS.

7. In the Alert Sender Address field, type the email address for the notification sender.



Note: The displayed sender address might be changed by the SMTP server. When sending through a Google SMTP server, for example, the sender email is changed to the username supplied for authentication, instead of the originally entered sender address.

8. (Optional) Select the Validate SSL Certificates checkbox to enable certificate validation.
If you select this option, the certificate on the remote endpoint is validated against the root certificate chains specified by the trusted certificates manager. Note that the host name specified in the certificate presented by the SMTP server must match the hostname specified in your SMTP configuration or validation will fail. In addition, you must configure which certificates you want to trust on the Trusted Certificates page. For more information, see [Add a trusted certificate to your ExtraHop system](#).
9. In the Report Sender Address field, type the email address responsible for sending the message.
This field is only applicable when sending scheduled reports from an ExtraHop console or RevealX 360.
10. Select the **Enable SMTP authentication** checkbox.
11. In the Username and Password fields, type the SMTP server setup credentials.
12. (Optional) Click **Test Settings**, type your email address (50 characters maximum), and then click **Send**.
You should receive an email message with the subject title `ExtraHop Test Email`.
13. Click **Save**.

Next steps

After you confirm that your new settings are working as expected, preserve your configuration changes through system restart and shutdown events by saving the running configuration file.

Add a new notification email address on an Explore or Trace appliance

You can send system storage alerts to individual recipients. Alerts are sent under the following conditions:

- A physical disk is in a degraded state.
 - A physical disk has an increasing error count.
 - (Explore appliance only) A virtual disk is in a degraded state.
 - (Explore appliance only) A registered Explore node is missing from the cluster. The node might have failed, or it is powered off.
1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
 2. In the Network Settings section, click **Notifications**.
 3. Under Notifications, click **Email Addresses**.
 4. In the **Email address** text box, type the recipient email address.

5. Click **Save**.

Configure settings to send notifications to an SNMP manager

The state of the network can be monitored through the Simple Network Management Protocol (SNMP). SNMP collects information by polling devices on the network. SNMP enabled devices can also send alerts to SNMP management stations. SNMP communities define the group where devices and management stations running SNMP belong, which specifies where information is sent. The community name identifies the group.



Note: Most organizations have an established system for collecting and displaying SNMP traps in a central location that can be monitored by their operations teams. For example, SNMP traps are sent to an SNMP manager, and the SNMP management console displays them.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Notifications**.
3. Under Notifications, click **SNMP**.
4. On the SNMP Settings page, in the **SNMP Monitor** field, type the hostname for the SNMP trap receiver.
Separate multiple hostnames with commas.
5. In the **SNMP Community** field, type the SNMP community name.
6. In the **SNMP Port** field, type the SNMP port number for your network that is used by the SNMP agent to respond back to the source port on the SNMP manager.
The default response port is 162.
7. (Optional) Click **Test Settings** to verify that your SNMP settings are correct.
If the settings are correct, you should see an entry in the SNMP log file on the SNMP server similar to this example, where 192.0.2.0 is the IP address of your ExtraHop system and 192.0.2.255 is the IP address of the SNMP server:
A response similar to this example displays:

```
Connection from UDP: [192.0.2.0]:42164->[ 192.0.2.255]:162
```

8. Click **Save**.

Download the ExtraHop SNMP MIB

SNMP does not provide a database of information that an SNMP-monitored network reports. SNMP information is defined by third-party management information bases (MIBs) that describe the structure of the collected data.

You can download the ExtraHop MIB file from the system's Administration settings.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. Go to the Network Settings section and click **Notifications**.
3. Under Notifications, click **SNMP**.
4. Under SNMP MIB, click the **Download ExtraHop SNMP MIB**.
The file is typically saved to the default download location for your browser.

Send system notifications to a remote syslog server

The syslog export option enables you to send alerts or audit logs from an ExtraHop system to any remote system that receives syslog input for long-term archiving and correlation with other sources.

Only one remote syslog server can be configured for each ExtraHop system.

You can send the following types of notifications to the syslog:

- Storage alert notifications
- ExtraHop [alert notifications](#)



Note: To send audit logs, see [Send audit log data to a remote syslog server](#)

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Notifications**, then click **Syslog**.
3. In the Destination field, type the IP address of the remote syslog server.
4. From the **Protocol** drop-down menu, select **TCP** or **UDP**.
This option specifies the protocol over which the information will be sent to your remote syslog server.
5. In the Port field, type the port number for your remote syslog server.
The default value is 514.
6. Click **Test Settings** to verify that your syslog settings are correct.
If the settings are correct, you should see an entry in the syslog log file on the syslog server similar to the following:

```
Jul 27 21:54:56 extrahop name="ExtraHop Test" event_id=1
```

7. Click **Save**.
8. (Optional) Modify the format of syslog messages.
By default, syslog messages are not compliant with RFC 3164 or RFC 5424. However, you can format syslog messages to be compliant by modifying the running configuration file.
 - a) Click **Admin**.
 - b) Click **Running Config (Unsaved Changes)**.
 - c) Click **Edit Config**.
 - d) Add an entry under `syslog_notification`, where the key is `rfc_compliant_format` and the value is either `rfc5424` or `rfc3164`.

The `syslog_notification` section should look similar to the following code:

```
"syslog_notification": {
  "syslog_destination": "192.168.0.0",
  "syslog_ipproto": "udp",
  "syslog_port": 514,
  "rfc_compliant_format": "rfc5424"
}
```

- e) Click **Update**.
 - f) Click **Done**.
9. (Optional) Modify the time zone referenced in syslog timestamps.
By default, syslog timestamps reference UTC time. However, you can modify timestamps to reference the ExtraHop system time by modifying the running configuration file.
 - a) Click **Admin**.
 - b) Click **Running Config (Unsaved Changes)**.
 - c) Click **Edit Config**.
 - d) Add an entry under `syslog_notification` where the key is `syslog_use_localtime` and the value is `true`.

The `syslog_notification` section should look similar to the following code:

```
"syslog_notification": {
  "syslog_destination": "192.168.0.0",
  "syslog_ipproto": "udp",
  "syslog_port": 514,
```

```
} "syslog_use_localtime": true
```

- e) Click **Update**.
- f) Click **Done**.


Next steps

After you confirm that your new settings are working as expected, preserve your configuration changes through system restart and shutdown events by saving the running configuration file.

TLS Certificate


TLS certificates provide secure authentication to the ExtraHop system.

You can designate a self-signed certificate for authentication instead of a certificate signed by a Certificate Authority. However, be aware that a self-signed certificate generates an error in the client browser, which reports that the signing certificate authority is unknown. The browser provides a set of confirmation pages to trust the certificate, even though the certificate is self-signed. Self-signed certificates can also degrade performance by preventing caching in some browsers. We recommend that you create a certificate-signing request from your ExtraHop system and upload the signed certificate instead.

 **Important:** When replacing an TLS certificate, the web server service is restarted. Tunneled connections from ExtraHop sensors to ExtraHop consoles are lost but then re-established automatically.

Upload a TLS certificate

You must upload a .pem file that includes both a private key and either a self-signed certificate or a certificate-authority certificate.


 **Note:** The .pem file must not be password protected.

 **Note:** You can also [automate this task through the REST API](#).

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **TLS Certificate**.
3. Click **Manage certificates** to expand the section.
4. Click **Choose File** and navigate to the certificate that you want to upload.
5. Click **Open**.
6. Click **Upload**.
7. [Save the running configuration file](#)

Generate a self-signed certificate

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **TLS Certificate**.
3. Click **Manage certificates** to expand the section.
4. Click **Build SSL self-signed certificate based on hostname**.
5. On the Generate Certificate page, click **OK** to generate the TLS self-signed certificate.

 **Note:** The default hostname is `extrahop`.

6. [Save the running configuration file](#)

Create a certificate signing request from your ExtraHop system

A certificate signing request (CSR) is a block of encoded text that is given to your Certificate Authority (CA) when you apply for an TLS certificate. The CSR is generated on the ExtraHop system where the TLS certificate will be installed and contains information that will be included in the certificate such as the common name (domain name), organization, locality, and country. The CSR also contains the public key that will be included in the certificate. The CSR is created with the private key from the ExtraHop system, making a key pair.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **TLS Certificate**.
3. Click **Manage certificates** and then click **Export a Certificate Signing Request (CSR)**.
4. In the Subject Alternative Names section, type the DNS name of the ExtraHop system.
You can add multiple DNS names and IP addresses to be protected by a single TLS Certificate.
5. In the Subject section, complete the following fields.
Only the **Common Name** field is required.

Field	Description	Examples
Common Name	The fully qualified domain name (FQDN) of the ExtraHop system. The FQDN must match one of the Subject Alternative Names.	*.example.com discover.example.com
E-mail Address	The email address of the primary contact for your organization.	webmaster@example.com
Organizational Unit	The division of your organization handling the certificate.	IT Department
Organization	The legal name of your organization. This entry should not be abbreviated and should include suffixes such as Inc, Corp, or LLC.	Example, Inc.
Locality/City	The city where your organization is located.	Seattle
State/Province	The state or province where your organization is located. This entry should not be abbreviated.	Washington
Country Code	The two-letter ISO code for the country where your organization is located.	US

6. Click **Export**.
The CSR file is automatically downloaded to your computer.

Next steps

Send the CSR file to your certificate authority (CA) to have the CSR signed. When you receive the TLS certificate from the CA, return to the TLS Certificate page in the Administration settings and upload the certificate to the ExtraHop system.



Tip: If your organization requires that the CSR contains a new public key, **generate a self-signed certificate** to create new key pairs before creating the CSR.

Trusted Certificates

Trusted certificates enable you to validate SMTP, LDAP, HTTPS ODS and MongoDB ODS targets, as well as Splunk recordstore connections from your ExtraHop system.


Add a trusted certificate to your ExtraHop system

Your ExtraHop system only trusts peers who present a Transport Layer Security (TLS) certificate that is signed by one of the built-in system certificates and any certificates that you upload. SMTP, LDAP, HTTPS ODS and MongoDB ODS targets, as well as Splunk recordstore connections can be validated through these certificates.

Before you begin

You must log in as a user with setup or system and access administration privileges to add or remove trusted certificates.

When uploading a custom trusted certificate, a valid trust path must exist from the uploaded certificate to a trusted self-signed root in order for the certificate to be fully trusted. Either upload the entire certificate chain for each trusted certificate or (preferably) ensure that each certificate in the chain has been uploaded to the trusted certificates system.

 **Important:** To trust the built-in system certificates and any uploaded certificates, you must also enable TLS or STARTTLS encryption and certificate validation when configuring the settings for the external server.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Network Settings section, click **Trusted Certificates**.
3. (Optional) If you want to trust the built-in certificates included in the ExtraHop system, select **Trust System Certificates**, click **Save**, and then [save the running configuration file](#).
4. To add your own certificate, click **Add Certificate** and then in the Certificate field, paste the contents of the PEM-encoded certificate chain.
5. In the Name field, type a name.
6. Click **Add**.

Access Settings

In the Access Settings section, you can change user passwords, enable the support account, manage local users and user groups, configure remote authentication, and manage API access.

Passwords

Users with privileges to the Administration page can change the password for local user accounts.

- Select any user and change their password
 - You can only change passwords for local users. You cannot change passwords for users authenticated through LDAP or other remote authentication servers.

For more information about privileges for specific Administration page users and groups, see the [Users](#) section.

Change the default password for the setup user

It is recommended that you change the default password for the setup user on the ExtraHop system after you log in for the first time. To remind administrators to make this change, there is a blue **Change Password** button at the top of the page while the setup user is accessing the Administration settings. After the setup user password is changed, the button at the top of the page no longer appears.



Note: The password must be a minimum of 5 characters.

1. In the Administration settings, click the blue **Change default password** button. The Password page displays without the drop-down menu for accounts. The password will change for the setup user only.
2. In the Old password field, type the default password.
3. In the New password field, type the new password.
4. In the Confirm password field, retype the new password.
5. Click **Save**.

Support Access

Support accounts provide access for the ExtraHop Support team to help customers troubleshoot issues with the ExtraHop system.

These settings should be enabled only if the ExtraHop system administrator requests hands-on assistance from the ExtraHop Support team.

Generate SSH key

Generate an SSH key to enable ExtraHop Support to connect to your ExtraHop system when [remote access](#) is configured through [ExtraHop Cloud Services](#).

1. In the Access Settings section, click **Support Access**.
2. Click **Generate SSH Key**.
3. Copy the encrypted key from the text box and email the key to your ExtraHop representative.
4. Click **Done**.

Regenerate or revoke the SSH key

To prevent SSH access to the ExtraHop system with an existing SSH key, you can revoke the current SSH key. A new SSH key can also be regenerated if needed.

1. In the Access Settings section, click **Support Access**.
2. Click **Generate SSH Key**.
3. Choose one of the following options:
 - Click **Regenerate SSH Key** and then click **Regenerate**.
Copy the encrypted key from the text box and email the key to your ExtraHop representative and then click **Done**.
 - Click **Revoke SSH Key** to prevent SSH access to the system with the current key.

Users

The Users page enables you to control local access to the ExtraHop appliance.

Users

Users can access recordstores and packetstores in three ways: through a set of pre-configured user accounts, through local user accounts configured on the appliance, or through remote user accounts configured on existing authentication servers, such as LDAP, SAML, Radius, and TACACS+. For RevealX 360, you can add user groups through the API

Local users

This topic is about default and local accounts. See [Remote Authentication](#) to learn how to configure remote accounts.

The following accounts are configured by default on ExtraHop systems but do not appear in the list of names on the Users page. These accounts cannot be deleted and you must change the default password upon initial login.

setup

This account provides full system read and write privileges to the browser-based user interface and to the ExtraHop command-line interface (CLI). For default login and password information, see [Default User Accounts FAQ](#).

shell

The `shell` account, by default, has access to non-administrative shell commands in the ExtraHop CLI. On physical sensors, the default password for this account is the service tag number on the front of the appliance. On virtual sensors, the default password is `default`.



Note: The default ExtraHop password for either account when deployed in Amazon Web Services (AWS) and Google Cloud Platform (GCP) is the instance ID of the virtual machine.

Next steps

- [Add a local user account to a console or sensor](#)
- [Add a local user account to a recordstore or packetstore](#)

Add a local user account

By adding a local user account, you can provide users with direct access to your recordstore or packetstore.

To learn about default system user accounts, see [Local users](#).



Note: Privileges can not be restricted for local users on recordstores and packetstores. All new local users are assigned full privileges.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.

2. In the Access Settings section, click **Users**.
3. Click **Add User**.
4. In the Personal Information section, in the Login ID field, type the username that users will log in to the sensor with, which cannot contain any spaces.
For example, adalovelace.
5. In the Full Name field, type a display name for the user.
The name can contain spaces. For example, Ada Lovelace.
6. In the Password field, type the password for this account.



Note: On sensors and consoles, the password must meet the criteria specified by the [global password policy](#). On ExtraHop recordstores and packetstores, passwords must be 5 characters or more.

7. In the Confirm Password field, re-type the password from the Password field.
8. Click **Save**.



- Tip:**
- To modify settings for a user, click the username from the list to bring up the Edit user page.
 - To delete a user account, click the red **X** icon. If you delete a user from a remote authentication server, such as LDAP, you must also delete the entry for that user on the ExtraHop system.

Remote Authentication

The ExtraHop system supports remote authentication for user access. Remote authentication enables organizations that have authentication systems such as LDAP (OpenLDAP or Active Directory, for example) to enable all or a subset of their users to log in to the system with their existing credentials.




Important: Menu selections vary depending on which appliance type you are configuring. For example, SAML is only available for sensors and consoles.

Centralized authentication provides the following benefits:

- User password synchronization.
- Automatic creation of ExtraHop accounts for users without administrator intervention.
- Management of ExtraHop privileges based on user groups.
- Administrators can grant access to all known users or restrict access by applying LDAP filters.

Next steps

- [Configure remote authentication through LDAP](#)
- [Configure remote authentication through SAML](#)  (Sensors and consoles only)
- [Configure remote authentication through TACACS+](#)
- [Configure remote authentication through RADIUS](#)

Remote users

If your ExtraHop system is configured for SAML or LDAP remote authentication, you can create an account for those remote users. Preconfiguring accounts on the ExtraHop system for remote users enables you to share system customizations with those users before they log in.

If you choose to auto-provision users when you configure SAML authentication, then the user is automatically added to the list of local users when they log in for the first time. However, you can create a remote SAML user account on the ExtraHop system when you want to provision a remote user before that user has logged in to the system. Privileges are assigned to the user by the provider. After the user is created, you can add them to local user groups.

Next steps


- [Add an account for a remote user](#) 

Sessions

The ExtraHop system provides controls to view and delete user connections to the web interface. The Sessions list is sorted by expiration date, which corresponds to the date the sessions were established. If a session expires or is deleted, the user must log in again to access the web interface.

Remote Authentication


The ExtraHop system supports remote authentication for user access. Remote authentication enables organizations that have authentication systems such as LDAP (OpenLDAP or Active Directory, for example) to enable all or a subset of their users to log in to the system with their existing credentials.

 **Important:** Menu selections vary depending on which appliance type you are configuring. For example, SAML is only available for sensors and consoles.

Centralized authentication provides the following benefits:

- User password synchronization.
- Automatic creation of ExtraHop accounts for users without administrator intervention.
- Management of ExtraHop privileges based on user groups.
- Administrators can grant access to all known users or restrict access by applying LDAP filters.


Next steps

- [Configure remote authentication through LDAP](#)
- [Configure remote authentication through SAML](#)  (Sensors and consoles only)
- [Configure remote authentication through TACACS+](#)
- [Configure remote authentication through RADIUS](#)

Configure remote authentication through LDAP


The ExtraHop system supports the Lightweight Directory Access Protocol (LDAP) for authentication and authorization. Instead of storing user credentials locally, you can configure your ExtraHop system to authenticate users remotely with an existing LDAP server. Note that ExtraHop LDAP authentication only queries for user accounts; it does not query for any other entities that might be in the LDAP directory.


Before you begin


- This procedure requires familiarity with configuring LDAP.
- Ensure that each user is in a permission-specific group on the LDAP server before beginning this procedure.
- If you want to configure nested LDAP groups, you must modify the Running Configuration file. Contact [ExtraHop Support](#)  for help.

When a user attempts to log onto an ExtraHop system, the ExtraHop system tries to authenticate the user in the following ways:

- Attempts to authenticate the user locally.
- Attempts to authenticate the user through the LDAP server if the user does not exist locally and if the ExtraHop system is configured for remote authentication with LDAP.
- Logs the user onto the ExtraHop system if the user exists and the password is validated either locally or through LDAP. The LDAP password is not stored locally on the ExtraHop system. Note that you must enter the username and password in the format that your LDAP server is configured for. The ExtraHop system only forwards the information to the LDAP server.
- If the user does not exist or an incorrect password is entered, an error message appears on the login page.

 **Important:** If you change LDAP authentication at a later time to a different remote authentication method, the users, user groups, and associated customizations that were created through remote authentication are removed. Local users are unaffected.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
 2. In the Access Settings section, click **Remote Authentication**.
 3. From the Remote authentication method drop-down menu, select **LDAP** and then click **Continue**.
 4. In the Hostname field, type the hostname or IP address of the LDAP server. If you are configuring a hostname, make sure that the DNS entry of the ExtraHop system is properly configured.
 5. In the Port field, type the port number on which the LDAP server is listening.
 6. From the **Server Type** drop-down menu, select **Posix** or **Active Directory**.
 7. (Optional) In the Bind DN field, type the bind DN. The bind DN is the user credentials that allow you to authenticate with the LDAP server to perform the user search. The bind DN must have list access to the base DN and any OU, groups, or user account required for LDAP authentication. If this value is not set, then an anonymous bind is performed. Note that anonymous binds are not enabled on all LDAP servers.
 8. (Optional) In the Bind Password field, type the bind password. The bind password is the password required when authenticating with the LDAP server as the bind DN specified above. If you are configuring an anonymous bind, leave this field blank. In some cases, an unauthenticated bind is possible, where you supply a Bind DN value but no bind password. Consult your LDAP administrator for the proper settings.
 9. From the **Encryption** drop-down menu, select one of the following encryption options.
 - **None:** This options specifies cleartext TCP sockets. All passwords are sent across the network in cleartext in this mode.
 - **LDAPS:** This option specifies LDAP wrapped inside TLS.
 - **StartTLS:** This option specifies TLS LDAP. (TLS is negotiated before any passwords are sent.)
 10. Select **Validate SSL Certificates** to enable certificate validation. If you select this option, the certificate on the remote endpoint is validated against the root certificates as specified by the trusted certificates manager. You must configure which certificates you want to trust on the Trusted Certificates page. For more information, see [Add a trusted certificate to your ExtraHop system](#).
 11. In the Refresh Interval field, type a time value or leave the default setting of 1 hour.
The refresh interval ensures that any changes made to user or group access on the LDAP server are updated on the ExtraHop system.
 12. In the Base DN field, type the base distinguished name (DN).
The Base DN is the point from where a server will search for users. Only user groups within the base DN can access the ExtraHop system. The users can be direct members of the base DN or nested within an OU within the base DN if the **Whole Subtree** option is selected for the Search Scope specified below.
-  **Important:** For recordstores and packetstores, all users that can access the recordstore or packetstore are granted administrative privileges. You can further restrict access with the Full Access DN field.
13. In the Search Filter field, type a search filter.
Search filters enable you to define search criteria when searching the LDAP directory for user accounts.

 **Important:** The ExtraHop system automatically adds parentheses to wrap the filter and will not parse this parameter correctly if you add parentheses manually. Add your search filters in this step and in step 5b, similar to the following example:

```
cn=atlas*
```

```
| ( cn=EH- * ) ( cn=IT- * )
```

In addition, if your group names include the asterisk (*) character, the asterisk must be escaped as \2a. For example, if your group has a CN called `test*group`, type `cn=test\2agroup` in the Search Filter field.


14. From the **Search Scope** drop-down menu, select one of the following options.

Search scope specifies the scope of the directory search when looking for user entities.


- **Whole subtree:** This option looks recursively under the group DN for matching users.
- **Single level:** This option looks for users that exist in the base DN only; not any subtrees.

15. For recordstores and packetstores, in the **Full Access DN** field, type a DN within the base DN.

This option further restricts recordstore or packetstore access to only the specified DN.

 **Important:** All users that can access the recordstore or packetstore are granted administrative privileges.

16. (Optional) For sensors and consoles, select the **Import user groups from LDAP server** checkbox and configure the following settings to import user groups.

 **Note:** Importing LDAP user groups enables you to share dashboards with those groups. The imported groups appear on the User Group page in the Administration settings.

- a) In the Base DN field, type the base DN.

The Base DN is the point from where a server will search for user groups. The base DN must contain all user groups that will have access to the ExtraHop system. The user groups can be direct members of the base DN or nested within an OU within the base DN if the **Whole Subtree** option is selected for the Search Scope specified below.

- b) In the Search Filter field type a search filter.

Search filters enable you to define search criteria when searching the LDAP directory for user groups.

 **Important:** For group search filters, the ExtraHop system implicitly filters on the `objectclass=group`, and so `objectclass=group` should not be added to this filter.

- c) From the **Search Scope** drop-down menu, select one of the following options.

Search scope specifies the scope of the directory search when looking for user group entities.

- **Whole subtree:** This option looks recursively under the base DN for matching user groups.
- **Single level:** This option looks for user groups that exist in the base DN; not any subtrees.

17. Click **Test Settings**.

If the test succeeds, a status message appears near the bottom of the page. If the test fails, click **Show details** to see a list of errors. You must resolve any errors before you continue.


18. Click **Save and Continue**.

Next steps

[Configure user privileges for remote authentication](#)

Configure user privileges for remote authentication

You can assign user privileges to individual users on your ExtraHop system or configure and manage privileges through your LDAP server.

 **Important:** This section applies only to sensors and consoles. For recordstores and packetstores, all users that can access the recordstore or packetstore are granted administrative privileges.

When assigning user privileges through LDAP, you must complete at least one of the available user privilege fields. These fields require groups (not organizational units) that are pre-specified on your LDAP server. A user account with access must be a direct member of a specified group. User accounts that

are not a member of a group specified above will not have access. Groups that are not present are not authenticated on the ExtraHop system.

The ExtraHop system supports both Active Directory and POSIX group memberships. For Active Directory, `memberOf` is supported. For POSIX, `memberuid`, `posixGroups`, `groupofNames`, and `groupofuniqueNames` are supported.

1. Choose one of the following options from the Privilege assignment options drop-down menu:

- **Obtain privileges level from remote server**

This option assigns privileges through your remote authentication server. You must complete at least one of the following distinguished name (DN) fields.

- **System and Access Administration DN:** Create and modify all objects and settings on the ExtraHop system, including Administration settings.
- **Full Write DN:** Create and modify objects on the ExtraHop system, not including Administration settings.
- **Limited Write DN:** Create, modify, and share dashboards.
- **Personal Write DN:** Create personal dashboards and modify dashboards shared with the logged-in user.
- **Full read-only DN:** View objects in the ExtraHop system.
- **Restricted Read-only DN:** View dashboards shared with the logged-in user.
- **Packet Slices Access DN:** View and download the first 64 bytes of packets captured through a packetstore.
- **Packet Headers Access DN:** Search and download only the packet headers of packets captured through a packetstore.
- **Packet Access DN:** View and download packets captured through a packetstore.
- **Packet and Session Keys Access DN:** View and download packets and any associated TLS session keys captured through a packetstore.
- **NDR Module Access DN:** View, acknowledge, and hide security detections that appear in the ExtraHop system.
- **NPM Module Access DN:** View, acknowledge, and hide performance detections that appear in the ExtraHop system.

- **Remote users have full write access**

This option grants remote users full write access to the ExtraHop system. In addition, you can grant additional access for packet downloads, TLS session keys, NDR module access, and NPM module access.

- **Remote users have full read-only access**

This option grants remote users read-only access to the ExtraHop system. In addition, you can grant additional access for packet downloads, TLS session keys, NDR module access, and NPM module access.

2. (Optional) Configure packet and session key access. Select one of the following options to allow remote users to download packet captures and TLS session keys.

- **No access**
- **Packet slices only**
- **Packet headers only**
- **Packets only**
- **Packets and session keys**

3. (Optional) Configure NDR and NPM module access (On sensors and consoles only).

- **No access**
 - **Full access**
4. Click **Save and Finish**.
 5. Click **Done**.

Configure remote authentication through RADIUS

The ExtraHop system supports Remote Authentication Dial In User Service (RADIUS) for remote authentication and local authorization only. For remote authentication, the ExtraHop system supports unencrypted RADIUS and plaintext formats.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Access Settings section, click **Remote Authentication**.
3. From the Remote authentication method drop-down menu, select **RADIUS** and then click **Continue**.
4. On the Add RADIUS Server page, type the following information:

Host

The hostname or IP address of the RADIUS server. Make sure that the DNS of the ExtraHop system is properly configured if you specify a hostname.

Secret

The shared secret between the ExtraHop system and the RADIUS server. Contact your RADIUS administrator to obtain the shared secret.

Timeout

The amount of time in seconds that the ExtraHop system waits for a response from the RADIUS server before attempting the connection again.

5. Click **Add Server**.
6. (Optional) Add additional servers as needed.
7. Click **Save and Finish**.
8. From the Privilege assignment options drop-down menu, choose one of the following options:
 - **Remote users have full write access**

This option grants remote users full write access to the ExtraHop system. In addition, you can grant additional access for packet downloads, TLS session keys, NDR module access, and NPM module access.
 - **Remote users have full read-only access**


This option grants remote users read-only access to the ExtraHop system. In addition, you can grant additional access for packet downloads, TLS session keys, NDR module access, and NPM module access.
9. (Optional) Configure packet and session key access. Select one of the following options to allow remote users to download packet captures and TLS session keys.
 - **No access**
 - **Packet slices only**
 - **Packet headers only**
 - **Packets only**
 - **Packets and session keys**
10. (Optional) Configure NDR and NPM module access (On sensors and consoles only).
 - **No access**
 - **Full access**
11. Click **Save and Finish**.

12. Click **Done**.


Configure remote authentication through TACACS+

The ExtraHop system supports Terminal Access Controller Access-Control System Plus (TACACS+) for remote authentication and authorization.

Ensure that each user to be remotely authorized has the [ExtraHop service configured on the TACACS+ server](#) before beginning this procedure.

 **Important:** For recordstores and packetstores, enabling remote access grants administrative privileges to all users in the TACACS+ authentication system, regardless of the privileges that the authentication system specifies for each user.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Access Settings section, click **Remote Authentication**.
3. From the Remote authentication method drop-down menu, select **TACACS+**, and then click **Continue**.
4. On the Add TACACS+ Server page, type the following information:
 - **Host:** The hostname or IP address of the TACACS+ server. Make sure that the DNS of the ExtraHop system is properly configured if you are entering a hostname.
 - **Secret:** The shared secret between the ExtraHop system and the TACACS+ server. Contact your TACACS+ administrator to obtain the shared secret.

 **Note:** The secret cannot include the number sign (#).

 - **Timeout:** The amount of time in seconds that the ExtraHop system waits for a response from the TACACS+ server before attempting to connect again.
5. Click **Add Server**.
6. (Optional) Add additional servers as needed.
7. Click **Save and Finish**.
8. For recordstores and packetstores, click **Done** and then skip to [configuring the TACACS+ server](#). For sensors and consoles, complete the remaining steps below.
9. From the Permission assignment options drop-down menu, choose one of the following options:
 - **Obtain privileges level from remote server**
This option allows remote users to obtain privilege levels from the remote server. You must also configure permissions on the TACACS+ server.
 - **Remote users have full write access**
This option grants remote users full write access to the ExtraHop system. In addition, you can grant additional access for packet downloads, TLS session keys, NDR module access, and NPM module access.
 - **Remote users have full read-only access**
This option grants remote users read-only access to the ExtraHop system. In addition, you can grant additional access for packet downloads, TLS session keys, NDR module access, and NPM module access.
10. (Optional) Configure packet and session key access. Select one of the following options to allow remote users to download packet captures and TLS session keys.
 - **No access**
 - **Packet slices only**
 - **Packet headers only**
 - **Packets only**
 - **Packets and session keys**

11. (Optional) Configure NDR and NPM module access (On sensors and consoles only).

- **No access**
- **Full access**

12. Click **Save and Finish**.


13. Click **Done**.

Configure the TACACS+ server

In addition to configuring remote authentication on your ExtraHop system, you must configure your TACACS+ server with two attributes, one for the ExtraHop service and one for the permission level. If you have an ExtraHop packetstore, you can optionally add a third attribute for packet capture and session key logging.

1. Log in to your TACACS+ server and navigate to the shell profile for your ExtraHop configuration.
2. For the first attribute, add `service`.
3. For the first value, add `extrahop`.
4. For the second attribute, add the privilege level, such as `readwrite`.
5. For the second value, add `1`.

For example, the following figure shows the `extrahop` attribute and a privilege level of `readwrite`.



Here is a table of available permission attributes, values, and descriptions:

Attribute	Value	Description
setup	1	Create and modify all objects and settings on the ExtraHop system and manage user access
readwrite	1	Create and modify all objects and settings on the ExtraHop system, not including Administration settings
limited	1	Create, modify, and share dashboards

Attribute	Value	Description
readonly	1	View objects in the ExtraHop system
personal	1	Create personal dashboards for themselves and modify any dashboards that have been shared with them
limited_metrics	1	View shared dashboards
ndrfull	1	View, acknowledge, and hide security detections
npmfull	1	View, acknowledge, and hide performance detections
packetsfull	1	View and download packets stored on a connected packetstore.
packetslicesonly	1	View and download packet slices on a connected packetstore.
packetheadersonly	1	Search and download only packet headers on a connected packetstore.
packetsfullwithkeys	1	View and download packets and associated session keys stored on a connected packetstore.

6. (Optional) Add the following attribute to allow users to view, acknowledge, and hide security detections

Attribute	Value
ndrfull	1

7. (Optional) Add the following attribute to allow users to view, acknowledge, and hide performance detections that appear in the ExtraHop system.

Attribute	Value
npmfull	1

8. (Optional) If you have an ExtraHop packetstore, add an attribute to allow users to download packet captures or packet captures with associated session keys.

Attribute	Value	Description
packetslicesonly	1	Users with any privilege level can view and download the first 64 bytes of packets.
packetheadersonly	1	Users with any privilege level can search and download

Attribute	Value	Description
		packet headers on a connected packetstore.
packetsfull	1	Users with any privilege level can view and download packets stored on a connected packetstore.
packetsfullwithkeys	1	Users with any privilege level can view and download packets and associated session keys stored on a connected packetstore.

API Access

The API Access page enables you to generate, view, and manage access for the API keys that are required to perform operations through the ExtraHop REST API.

Manage API key access

Users with system and access administration privileges can configure whether users can generate API keys for the ExtraHop system. You can allow only local users to generate keys, or you can also disable API key generation entirely.

Users must generate an API key before they can perform operations through the ExtraHop REST API. Keys can be viewed only by the user who generated the key or system administrators with unlimited privileges. After a user generates an API key, they must append the key to their request headers.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Access Settings section, click **API Access**.
3. In the Manage API Access section, select one of the following options:
 - **Allow all users to generate an API key:** Local and remote users can generate API keys.
 - **Only local users can generate an API key:** Remote users cannot generate API keys.
 - **No users can generate an API key:** No API keys can be generated by any user.
4. Click **Save Settings**.

Configure cross-origin resource sharing (CORS)

Cross-origin resource sharing (CORS) allows you to access the ExtraHop REST API across domain-boundaries and from specified web pages without requiring the request to travel through a proxy server.

You can configure one or more allowed origins or you can allow access to the ExtraHop REST API from any origin. Only users with system and access administration privileges can view and edit CORS settings.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Access Settings section, click **API Access**.
3. In the CORS Settings section, specify one of the following access configurations.
 - To add a specific URL, type an origin URL in the text box, and then click the plus (+) icon or press ENTER.

The URL must include a scheme, such as HTTP or HTTPS, and the exact domain name. You cannot append a path; however, you can provide a port number.

- To allow access from any URL, select the **Allow API requests from any Origin** checkbox.



Note: Allowing REST API access from any origin is less secure than providing a list of explicit origins.

4. Click **Save Settings** and then click **Done**.

Generate an API key

You must generate an API key before you can perform operations through the ExtraHop REST API. Keys can be viewed only by the user who generated the key or by users with system and access administration privileges. After you generate an API key, add the key to your request headers or the ExtraHop REST API Explorer.

Before you begin

Make sure the ExtraHop system is **configured to allow API key generation**.

1. In the Access Settings section, click **API Access**.
2. In the Generate an API Key section, type a description for the new key, and then click **Generate**.
3. Scroll down to the API Keys section and copy the API key that matches your description.

You can paste the key into the REST API Explorer or append the key to a request header.

Privilege levels

User privilege levels determine which ExtraHop system and administration tasks the user can perform through the ExtraHop REST API.

You can view the privilege levels for users through the `granted_roles` and `effective_roles` properties. The `granted_roles` property shows you which privilege levels are explicitly granted to the user. The `effective_roles` property shows you all privilege levels for a user, including those received outside of the granted role, such as through a user group.

The `granted_roles` and `effective_roles` properties are returned by the following operations:

- GET /users
- GET /users/{username}

The `granted_roles` and `effective_roles` properties support the following privilege levels. Note that the type of tasks for each ExtraHop system vary by the available **resources** [↗](#) listed in the REST API Explorer and depend on the modules enabled on the system and user module access privileges.

Privilege level	Actions allowed
"system": "full"	<ul style="list-style-type: none"> • Enable or disable API key generation for the ExtraHop system. • Generate an API key. • View the last four digits and description for any API key on the system. • Delete API keys for any user. • View and edit cross-origin resource sharing. • Perform any administration task available through the REST API. • Perform any ExtraHop system task available through the REST API.
"write": "full"	<ul style="list-style-type: none"> • Generate your own API key. • View or delete your own API key. • Change your own password, but you cannot perform any other administration tasks through the REST API. • Perform any ExtraHop system task available through the REST API.

Privilege level	Actions allowed
"write": "limited"	<ul style="list-style-type: none"> • Generate an API key. • View or delete their own API key. • Change your own password, but you cannot perform any other administration tasks through the REST API. • Perform all GET operations through the REST API. • Perform metric and record queries.
"write": "personal"	<ul style="list-style-type: none"> • Generate an API key. • View or delete your own API key. • Change your own password, but you cannot perform any other administration tasks through the REST API. • Perform all GET operations through the REST API. • Perform metric and record queries.
"metrics": "full"	<ul style="list-style-type: none"> • Generate an API key. • View or delete your own API key. • Change your own password, but you cannot perform any other administration tasks through the REST API. • Perform metric and record queries.
"metrics": "restricted"	<ul style="list-style-type: none"> • Generate an API key. • View or delete your own API key. • Change your own password, but you cannot perform any other administration tasks through the REST API.
"ndr": "full"	<ul style="list-style-type: none"> • View security detections • View and create investigations <p>This is a module access privilege that can be granted to a user in addition to one of the following system access privilege levels:</p> <ul style="list-style-type: none"> • "write": "full" • "write": "limited" • "write": "personal" • "write": null • "metrics": "full" • "metrics": "restricted"
"ndr": "none"	<ul style="list-style-type: none"> • No access to NDR module content <p>This is a module access privilege that can be granted to a user in addition to one of the following system access privilege levels:</p> <ul style="list-style-type: none"> • "write": "full" • "write": "limited" • "write": "personal" • "write": null • "metrics": "full" • "metrics": "restricted"
"npm": "full"	<ul style="list-style-type: none"> • View performance detections • View and create dashboards

Privilege level	Actions allowed
	<ul style="list-style-type: none"> View and create alerts <p>This is a module access privilege that can be granted to a user in addition to one of the following system access privilege levels:</p> <ul style="list-style-type: none"> "write": "full" "write": "limited" "write": "personal" "write": null "metrics": "full" "metrics": "restricted"
"npm": "none"	<ul style="list-style-type: none"> No access to NPM module content <p>This is a module access privilege that can be granted to a user in addition to one of the following system access privilege levels:</p> <ul style="list-style-type: none"> "write": "full" "write": "limited" "write": "personal" "write": null "metrics": "full" "metrics": "restricted"
"packets": "full"	<ul style="list-style-type: none"> View and download packets through the GET /packets/search and POST /packets/search operations. <p>This is an add-on privilege that can be granted to a user with one of the following privilege levels:</p> <ul style="list-style-type: none"> "write": "full" "write": "limited" "write": "personal" "write": null "metrics": "full" "metrics": "restricted"
"packets": "full_with_keys"	<ul style="list-style-type: none"> View and download packets and session keys through the GET /packets/search and POST /packets/search operations. <p>This is an add-on privilege that can be granted to a user with one of the following privilege levels:</p> <ul style="list-style-type: none"> "write": "full" "write": "limited" "write": "personal" "write": null "metrics": "full" "metrics": "restricted"
"packets": "slices_only"	<ul style="list-style-type: none"> View and download the first 64 bytes of packets through the GET /packets/search and POST /packets/search operations. <p>This is an add-on privilege that can be granted to a user with one of the following privilege levels:</p>

Privilege level	Actions allowed
	<ul style="list-style-type: none">• "write": "full"• "write": "limited"• "write": "personal"• "write": null• "metrics": "full"• "metrics": "restricted"

Appliance Settings

You can configure the following components of the ExtraHop appliance in the Appliance Settings section. All appliances have the following components:

Running Config

Download and modify the running configuration file.

Services

Enable or disable the Web Shell, management GUI, SNMP service, SSH access, and TLS session key receiver. The SSL Session Key Receiver option appears only on packet sensors.

Firmware

Upgrade the ExtraHop system firmware.

System Time

Configure the system time.

Shutdown or Restart

Halt and restart system services.

License

Update the license to enable add-on modules.

Disks

Provides information about the disks in the appliance.

The following components only appear on the specified appliances:

Console Nickname

Assign a nickname to an ExtraHop console. This setting is available only on the console.

Reset Packetstore

Delete all packets stored on ExtraHop packetstores. The Reset Packetstore page appears only on packetstores.

Running Config

The running configuration file specifies the default system configuration. When you modify system settings, you must save the running configuration file to preserve those modifications after a system restart.




Note: Making configuration changes to the code from the Edit page is not recommended. You can make most system modifications through other pages in the Administration settings.

Save system settings to the running configuration file

When you modify any of the system configuration settings on an ExtraHop system, you must confirm the updates by saving the running configuration file. If you do not save the settings, the changes are lost when your ExtraHop system restarts.

To remind you that the running configuration has changed, (Unsaved changes) appears next to the Running Config link on the main Administration settings page, as well as a **View and Save Changes** button on all Administration settings pages.


1. Click **View and Save Changes**.



2. Review the comparison between the old running configuration and the current (unsaved) running configuration, and then select from the following options:
 - If the changes are correct, click **Save**.
 - If the changes are not correct, click **Cancel** and then revert the changes by clicking **Revert config**.

Edit the running configuration file

The ExtraHop Administration settings provide an interface to view and modify the code that specifies the default system configuration. In addition to making changes to the running configuration file through the Administration settings, you can also make changes on the Running Config page.

 **Important:** Making configuration changes to the code from the Edit page is not recommended. You can make most system modifications through other Administration settings.

Download the running configuration as a text file

You can download the running configuration file to your workstation. You can open this text file and make changes to it locally, before copying those changes into the Running Config window.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **Running Config**.
3. Click **Download config as a file**.

The current running configuration file is downloaded as a text file to your default download location.

Disable ICMPv6 Destination Unreachable messages

You can prevent the ExtraHop system from generating ICMPv6 Destination Unreachable messages. You might want to disable ICMPv6 Destination Unreachable messages for security reasons per RFC 4443.

To disable ICMPv6 Destination Unreachable messages, you must edit the Running Configuration. However, we recommend that you do not manually edit the Running Configuration file without direction from ExtraHop Support. Manually editing the running configuration file incorrectly might cause the system to become unavailable or stop collecting data. You can contact [ExtraHop Support](#).

Disable specific ICMPv6 Echo Reply messages

You can prevent the ExtraHop system from generating Echo Reply messages in response to ICMPv6 Echo Request messages that are sent to an IPv6 multicast or anycast address. You might want to disable these messages to reduce unnecessary network traffic.


To disable specific ICMPv6 Echo Reply messages, you must edit the running configuration file. However, we recommend that you do not manually edit the running configuration file without direction from ExtraHop Support. Manually editing this file incorrectly might cause the system to become unavailable or stop collecting data. You can contact [ExtraHop Support](#).

Services

These services run in the background and perform functions that do not require user input. These services can be started and stopped through the Administration settings.

Enable or disable the Management GUI

The Management GUI provides browser-based access to the ExtraHop system. By default, this service is enabled so that ExtraHop users can access the ExtraHop system through a web browser. If this service is disabled, the Apache Web Server session is terminated and all browser-based access is disabled.

 **Warning:** Do not disable this service unless you are an experienced ExtraHop administrator and you are familiar with the ExtraHop CLI.


Enable or disable the SNMP Service

Enable the SNMP service on the ExtraHop system when you want your network device monitoring software to collect information about the ExtraHop system. This service is disabled by default.

- Enable the SNMP service from the Services page by selecting the Disabled checkbox and then clicking **Save**. After the page refreshes, the Enabled checkbox appears.
- [Configure the SNMP service](#) and download the ExtraHop MIB file


Enable or disable SSH Access

SSH access is enabled by default to enable users to securely log in to the ExtraHop command-line interface (CLI).

 **Note:** The SSH Service and the Management GUI Service cannot be disabled at the same time. At least one of these services must be enabled to provide access to the system.

Enable or disable the TLS Session Key Receiver (Sensor only)

You must enable the session key receiver service through the Administration settings before the ExtraHop system can receive and decrypt session keys from the session key forwarder. By default, this service is disabled.

 **Note:** If you do not see this checkbox and have purchased the TLS Decryption license, contact [ExtraHop Support](#) to update your license.

SNMP Service

Configure the SNMP service on your ExtraHop system so that you can configure your network device monitoring software to collect information about your ExtraHop system through the Simple Network Management Protocol (SNMP).

For example, you can configure your monitoring software to determine how much free space is available on an ExtraHop system and send an alert if the system is over 95% full. Import the ExtraHop SNMP MIB file into your monitoring software to monitor all ExtraHop-specific SNMP objects. You can configure settings for SNMPv1/SNMPv2 and SNMPv3.

Firmware


The Administration settings provide an interface to upload and delete the firmware on ExtraHop appliances. The firmware file must be accessible from the computer where you will perform the upgrade.


Before you begin

Be sure to read the [release notes](#) for the firmware version that you want to install. Release notes contain upgrade guidance as well as known issues that might affect critical workflows in your organization.

Upgrade the firmware on your ExtraHop system




The following procedure shows you how to upgrade your ExtraHop system to the latest firmware release. While the firmware upgrade process is similar across all ExtraHop appliances, some appliances have additional considerations or steps that you must address before you install the firmware in your environment. If you need assistance with your upgrade, contact ExtraHop Support.

 **Video:** the related training: [Update Firmware](#) 

 **Important:** When settings migration fails during firmware upgrade, the previously installed firmware version and ExtraHop system settings are restored.

Pre-upgrade checklist

Here are some important considerations and requirements about upgrading ExtraHop appliances.

- A system notice appears on consoles and sensors connected to ExtraHop Cloud Services when a new firmware version is available.
- Verify that your RevealX 360 system has been upgraded to version 9.9 before upgrading your sensors.
- If you are upgrading from firmware version 8.7 or earlier, contact ExtraHop Support for additional upgrade guidance.
- If you are upgrading a virtual ExtraHop sensor deployed on a [VMware ESXi/ESX](#) , [Microsoft Hyper-V](#) , or [Linux KVM](#)  platform from firmware version 9.6 or earlier, the VM must support Streaming SIMD Extensions 4.2 (SSE4.2) and POPCNT instruction; otherwise, the upgrade will fail.
- If you have multiple types of ExtraHop appliances, you must upgrade them in the following order:
 1. Console
 2. Sensors (EDA and Ultra)
 3. Recordstores
 4. Packetstores



Note: Your browser might time out after 5 minutes of inactivity. Refresh the browser page if the update appears incomplete.


If the browser session times out before the ExtraHop system is able to complete the update process, you can try the following connectivity tests to confirm the status up the upgrade process:


- Ping the appliance from the command line of another appliance or client workstation.
- From the Administration settings on a console, view the appliance status on the Manage Connected Appliances page.
- Connect to the appliance through the iDRAC interface.

Console upgrades

- For large console deployments (managing 50,000 devices or more), reserve a minimum of one hour to perform the upgrade.
- The console firmware version must be greater than or equal to the firmware version of all connected appliances. To ensure feature compatibility, all connected appliances should be running firmware version 8.7 or later.

Recordstore upgrades

- Do not upgrade recordstores to a firmware version that is newer than the version installed on connected consoles and sensors.
- After upgrading the console and sensors, [disable record ingest on the recordstore](#)  before upgrading the recordstore.
- You must upgrade all recordstore nodes in a recordstore cluster. The cluster will not function correctly if nodes are on dissimilar firmware versions.

 **Important:** The messages `Could not determine ingest status on some nodes` and `Error` appear on the Cluster Data Management page in the Administration settings of the upgraded nodes until all nodes in the cluster are upgraded. These errors are expected and can be ignored.

- You must enable record ingest and shard reallocation from the Cluster Data Management page after all nodes in the recordstore cluster are upgraded.

Packetstore upgrades

- Do not upgrade packetstores to a firmware version that is newer than the version installed on connected consoles and sensors.

Upgrade the firmware on a console and sensor

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **Firmware**.
3. From the **Available Firmware** drop-down menu, select the version of firmware that you want to install. The recommended version is selected by default.



Note: For sensors, the list includes only firmware versions that are compatible with the version running on the connected console.

4. Click **Download and Install**.

After the firmware upgrade installs successfully, the ExtraHop appliance restarts.

Upgrade the firmware on recordstores

1. Download the firmware for the appliance from the [ExtraHop Customer Portal](#) to your computer.
2. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
3. Click **Cluster Data Management**.
4. Click **Disable Record Ingest**.
5. Click **Admin** to return to the main Administration page.
6. Click **Firmware**.
7. Click **uploading a file or specifying a URL**.
8. On the Upgrade Firmware page, select one of the following options:
 - To upload firmware from a file, click **Choose File**, navigate to the `.tar` file you want to upload, and click **Open**.
 - To upload firmware from an HTTP(s) staging server on your network, click **retrieve from URL instead** and then type the URL in the Firmware URL field.
9. Click **Upgrade**.
The ExtraHop system initiates the firmware upgrade. You can monitor the progress of the upgrade with the Updating progress bar. The appliance restarts after the firmware is installed.
10. Repeat steps 6-9 on all remaining recordstore cluster nodes.

Next steps

After all nodes in the recordstore cluster are upgraded, re-enable record ingest and shard reallocation on the cluster. You only need to perform these steps on one recordstore node.

1. In the Recordstore Cluster Settings section, click **Cluster Data Management**.
2. Click **Enable Record Ingest**.
3. Click **Enable Shard Reallocation**.

Upgrade the firmware on packetstores

1. Download the firmware for the appliance from the [ExtraHop Customer Portal](#) to your computer.
2. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
3. Click **uploading a file or specifying a URL**.
4. On the Upgrade Firmware page, select one of the following options:
 - To upload firmware from a file, click **Choose File**, navigate to the `.tar` file you want to upload, and click **Open**.
 - To upload firmware from an HTTP(s) staging server on your network, click **retrieve from URL instead** and then type the URL in the Firmware URL field.
5. (Optional) If you do not want to automatically restart the appliance after the firmware is installed, clear the **Automatically restart appliance after installation** checkbox.
6. Click **Upgrade**.
The ExtraHop system initiates the firmware upgrade. You can monitor the progress of the upgrade with the Updating progress bar. The appliance restarts after the firmware is installed.
7. If you did not choose to automatically restart the appliance, click **Reboot** to restart the system.
After the firmware update is installed successfully, the ExtraHop appliance displays the version number of the new firmware on the Administration settings.


Upgrade connected sensors in RevealX 360

Administrators can upgrade sensors that are connected to RevealX 360.



Before you begin

- Your user account must have privileges on RevealX 360 for System and Access Administration or System Administration.

Here are some considerations about upgrading sensors:

- Sensors must be connected to ExtraHop Cloud Services
 - Notifications appear when a new firmware version is available
 - You can upgrade multiple sensors at the same time
1. From the Overview page, click **System Settings**  and then click **Sensors**.

Sensors that are eligible for upgrade display an up arrow in the Sensor Version field.

Sensors							
Name 		≈ 		4 results		⬆ New firmware is available.	
<input type="checkbox"/>	Name ↑	Sensor Model	Status	License	Sensor Version	Sensor Tags	Date Added
<input type="checkbox"/>	sensor-1	EDA6320V	Online	Valid	⬆ 9.8.0.1760	—	2024-09
<input type="checkbox"/>	sensor-2	EDA6320V	Online	Valid	⬆ 9.8.0.1760	RegionA, exampleTag	2024-08
<input type="checkbox"/>	sensor-3	EDA1100V	Online	Valid	⬆ 9.8.0.1760	—	2024-08
<input type="checkbox"/>	sensor-4	EDA1100V	Online	Valid	⬆ 9.8.0.1760	RegionB	2024-08

2. Select the checkbox next to each sensor that you want to upgrade.
3. In the Sensor Details pane, select the firmware version from the **Available Firmware** drop-down menu.
The drop-down menu only displays versions that are compatible with the selected sensors.
Only the selected sensors that have a firmware upgrade available appear in the Sensor Details pane.
4. Click **Install Firmware**.

When the upgrade completes, the Sensor Version field is updated with the new firmware version.

System Time

The System Time page displays the current time settings configured for your ExtraHop system. View the current system time settings, the default display time for users, and details for configured NTP servers.

System time is the time and date tracked by services running on the ExtraHop system to ensure accurate time calculations. By default, the system time on the sensor or console is configured locally. For better accuracy, we recommend that you configure the system time through an NTP time server.

When capturing data, the system time must match the time on connected sensors to ensure that time stamps are correct and complete in scheduled reports, exported dashboards and chart metrics. If time sync issues occur, check that the configured system time, external time servers, or NTP servers are accurate.

[Reset the system time](#) or [sync NTP servers](#) if needed

The table below contains details about the current system time configuration. Click **Configure Time** to [configure system time settings](#).

Detail	Description
Time Zone	Displays the currently selected time zone.
System Time	Displays the current system time.
Time Servers	Displays a comma-separated list of configured time servers.

Default display time for users

The Default Display Time for Users section shows the time displayed to all users in the ExtraHop system unless a user manually [changes their displayed time zone](#).

To modify the default display time, select one of the following options and then click **Save Changes**:

- Browser time
- System time
- UTC

NTP Status

The NTP Status table displays the current configuration and status of all NTP servers that keep the system clock in sync. The table below contains details about each configured NTP server. Click **Sync Now** to sync the current system time to a remote server.

remote	The host name or IP address of the remote NTP server you have configured to synchronize with.
st	The stratum level, 0 through 16.
t	The type of connection. This value can be <code>u</code> for unicast or <code>m</code> for multicast, <code>b</code> for broadcast or <code>l</code> for local reference clock, <code>s</code> for symmetric peer, <code>A</code> for a manycast server, <code>B</code> for a broadcast server, or <code>M</code> for a multicast server.
when	The last time when the server was queried for the time. The default value is seconds, or <code>m</code> is displayed for minutes, <code>h</code> for hours, and <code>d</code> for days.
poll	How often the server is queried for the time, with a minimum of 16 seconds to a maximum of 36 hours.

reach	Value that shows the success and failure rate of communicating with the remote server. Success means the bit is set, failure means the bit is not set. 377 is the highest value.
delay	The round trip time (RTT) of the ExtraHop appliance communicating with the remote server, in milliseconds.
offset	Indicates how far off the ExtraHop appliance clock is from the time reported by the server. The value can be positive or negative, displayed in milliseconds.
jitter	Indicates the difference, in milliseconds, between two samples.

Configure the system time

By default, the ExtraHop system synchronizes the system time through the *.extrahop.pool.ntp.org network time protocol (NTP) servers. If your network environment prevents the ExtraHop system from communicating with these time servers, you must configure an alternate time server source.

Before you begin

 **Important:** Always configure more than one NTP server to increase the accuracy and reliability of time kept on the system.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **System Time**.
3. Click **Configure Time**.
4. From the **Select time zone** drop-down menu, select your time zone.
5. Click **Save and Continue**.
6. On the Time Setup page, select one of the following options:
 - Set time manually



Note: You cannot manually set the time for sensors that are managed by a console or RevealX 360.

- Set time with NTP server
7. Select **Set time with NTP server** and then click **Select**.
The ExtraHop time servers, 0.extrahop.pool.ntp.org, 1.extrahop.pool.ntp.org, 2.extrahop.pool.ntp.org, and 3.extrahop.pool.ntp.org appear in the first four Time Server fields by default.
 8. In the Time Server fields, type the IP address or fully qualified domain name (FQDN) for the time servers.

You can specify up to nine time servers.



Tip: After adding the fifth time server, click **Add Server** to display up to four additional timer server fields.

9. Click **Done**.

The NTP Status table displays a list of NTP servers that keep the system clock in sync. To sync the current system time a remote server, click the **Sync Now** button.

Shutdown or restart

You can shut down or restart the Trace appliance in the Administration settings.

1. In the Appliance Settings section, click **Shutdown or Restart**.
2. In the Actions column, select one of the following options:

- Click **Restart** and then on the confirmation page, click **Restart** to restart the appliance.
- Click **Shutdown**, and then on the confirmation page, click **Shut down** to shut down the system and power off the appliance.

License

The Administration settings provide an interface to add and update licenses for add-in modules and other features available in the ExtraHop system. The License Administration page includes the following licensing information and settings:

Manage license

Provides an interface to add and update the ExtraHop system

System Information

Displays the identification and expiration information about the ExtraHop system.

Features

Displays the list of licensed features and whether the licensed features are enabled or disabled.

Register your ExtraHop system

This guide provides instructions on how to apply a new product key and activate all of your purchased modules. You must have privileges on the ExtraHop system to access the Administration settings.

Register the appliance

Before you begin



Note: If you are registering a sensor or a console, you can optionally enter the product key after you accept the EULA and log in to the ExtraHop system (`https://<extrahop-hostname-or-IP-address>/`
`<extrahop_ip_address>/`).

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. Review the license agreement, select **I Agree**, and then click **Submit**.
3. On the login screen, type `setup` for the username.
4. For the password, select from the following options:
 - For 1U and 2U appliances, type the serial number printed on the label on the back of the appliance. The serial number can also be found on the LCD display on the front of the appliance in the `Info` section.
 - For the EDA 1100, type the serial number displayed in the `Appliance info` section of the LCD menu. The serial number is also printed on the bottom of the appliance.
 - For the EDA 1200, type the serial number printed on the back of the appliance.
 - For a virtual appliance in AWS, type the instance ID, which is the string of characters that follow `i-` (but not `i-` itself).
 - For a virtual appliance in GCP, type the instance ID.
 - For all other virtual appliances, type `default`.
5. Click **Log In**.
6. In the Appliance Settings section, click **License**.
7. Click **Manage License**.
8. If you have a product key, click **Register** and type your product key into the field.



Note: If you received a license file from ExtraHop Support, click **Manage License**, click **Update**, then paste the contents of the file into the Enter License field. Click **Update**.

9. Click **Register**.

Next steps

Have more questions about ExtraHop licensing works? See the [License FAQ](#).

Troubleshoot license server connectivity

For ExtraHop systems licensed and configured to connect to ExtraHop Cloud Services, registration and verification is performed through an HTTPS request to ExtraHop Cloud Services.

If your ExtraHop system is not licensed for ExtraHop Cloud Services or is not yet licensed, the system attempts to register the system through a DNS TXT request for `regions.hopcloud.extrahop.com` and an HTTPS request to all [ExtraHop Cloud Services regions](#). If this request fails, the system tries to connect to the ExtraHop licensing server through DNS server port 53. The following procedure is useful to verify that the ExtraHop system can communicate with the licensing server through DNS.

Open a terminal application on your Windows, Linux, or macOS client that is on the same network as your ExtraHop system and run the following command:

```
nslookup -type=NS d.extrahop.com
```

If the name resolution is successful, output similar to the following appears:

```
Non-authoritative answer:
d.extrahop.com  nameserver = ns0.use.d.extrahop.com.
d.extrahop.com  nameserver = ns0.usw.d.extrahop.com.
```


If the name resolution is not successful, make sure that your DNS server is properly configured to lookup the `extrahop.com` domain.

Apply an updated license

When you purchase a new protocol module, service, or feature, the updated license is automatically available on the ExtraHop system. However you must apply the updated license to the system through the Administration settings for the new changes to take effect.

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **License**.

A message appears about the availability of your new license.



3. Click **Apply new license**.

The capture process restarts, which might take a few minutes.



Note: If your license is not automatically updated, [troubleshoot licensing server connectivity](#) or contact ExtraHop Support.

Update a license

If ExtraHop Support provides you with a license file, you can install this file on your appliance to update the license.



Note: If you want to update the product key for your appliance, you must [register your ExtraHop system](#).

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **License**.
3. Click Manage License.
4. Click **Update**.
5. In the Enter License text box, enter the licensing information for the module.
Paste the license text provided to you by ExtraHop Support. Be sure to include all of the text, including the BEGIN and END lines, as shown in the example below:

```
-----BEGIN EXTRAHOP LICENSE-----
serial=ABC123D;
dossier=1234567890abcdef1234567890abcdef;
mod_cifs=1;
mod_nfs=1;
mod_amf=0;
live_capture=1;
capture_upload=1;
...
ssl_decryption=0;
+++;
ABcAbcDE/FGHIjklm12nopqrstuvwxyzXYZAB12345678abcde901abCD;
12ABCDEFGH1HIJklmnOP+1aA=;
=abcd;
-----END EXTRAHOP LICENSE-----
```

6. Click **Update**.

Disks

The Disks page provides information about the configuration and status of the disks in your Trace appliance as well the disks in any attached storage units.



Note: We recommend that you configure the settings to receive [email notifications](#) about your system health. If a disk is beginning to experience problems, you will be alerted.

The following information displays on the page:

Drive Map

Provides a visual representation of the front of the Trace appliance. The drive map does not appear in the Administration settings on the virtual Trace appliance.

RAID Disk Details

Provides access to detailed information about all the disks in the node.

Packetstore

Displays information about disks reserved for packet storage and the option to encrypt the packetstore disk. For more information, see the [Encrypt the packetstore disk](#) section.

Direct Connected Disks

Displays information about the SD memory cards. The memory cards have the following roles:

Firmware

Displays information about disks reserved for the firmware.

Utility


Displays information about disks reserved for system files.

Extended Storage Units


Displays information about ExtraHop extended storage units.

Encrypt the packetstore disk

You can encrypt the disk, including attached extended storage units that packet captures are stored on for increased security. The packetstore disk is secured with 256-bit AES encryption.

 **Warning:** You cannot decrypt a packetstore disk after it is encrypted. You can reformat an encrypted disk; however, all data stored on the disk will be lost. To perform a secure delete (secure wipe) of all system data, see the [ExtraHop Rescue Media Guide](#).

 **Warning:** When you encrypt a packetstore disk, all packets stored on the disk are deleted.

 **Important:** The packetstore is locked when the ETA appliance is restarted. Before packets can be written to disk, you must unlock the disk from the Packetstore Encryption Settings page.

1. In the Appliance Settings section, click **Disks**.
2. Navigate to the Packetstore Encryption Settings page.

Option	Description
For virtual appliances	In the Direct Connected Disks table, click Settings .
For physical appliances	In the Packetstore section, next to Packetstore Encryption, click Settings .
3. Click **Encrypt Packetstore**.
4. Specify a disk encryption key by choosing one of the following options.
 - To encrypt the disk with a passphrase, type a passphrase of at least 8 characters into the Passphrase and Confirm fields. The passphrase must contain a combination of uppercase letters, lowercase letters, numbers, and special characters.
 - To encrypt the disk with a key file, click **Choose File**, and then browse to an encryption key file.
5. Click **Encrypt**.

Change the packet capture disk encryption key

1. In the Status section, click **Disks**.
2. In the Datastore section, click **Packetstore Encryption Settings**.
3. Click **Change Packetstore Encryption Key**.
4. Specify the existing encryption key.

Option	Description
If you entered an encryption passphrase	Type a passphrase into the Passphrase field.
If you selected an encryption key file	Click Choose File , and then browse to an encryption key file.
5. Specify a new disk encryption key.

Option	Description
To enter an encryption passphrase	Type a passphrase into the Passphrase and Confirm fields.
To select an encryption key file	Click Choose File , and then browse to an encryption key file.
6. Click **Change Key**.

Add storage capacity to an ExtraHop packetstore

Adding storage capacity to your ExtraHop packetstore enables you to store more packets and extend the amount of lookback available when running packet queries. You can safely add ExtraHop Extended Storage Units (ESUs) to a packetstore and retain all packets currently stored on the packetstore.

Managing extended storage units with a foreign packetstore status

When an extended storage unit with an existing RAID configuration is connected to a RAID controller on the Trace appliance, the extended storage unit is designated as “foreign”. This status can occur when an extended storage unit was previously connected and then disconnected from the RAID controller on the Trace appliance and when the extended storage unit was configured on a RAID controller other than the Trace appliance it was originally connected to.

For extended storage units disconnected and then reconnected to the same Trace appliance

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **Disks**.
3. Click **Extended Storage Units**.
4. Click **Import foreign packetstore disks**.
The extended storage unit is automatically configured and ready to store packets.

For extended storage units configured on a device other than the Trace appliance

1. Log in to the Administration settings on the ExtraHop system through `https://<extrahop-hostname-or-IP-address>/admin`.
2. In the Appliance Settings section, click **Disks**.
3. Click **Extended Storage Units**.
4. Click **Import foreign packetstore disks**, and then click **OK**.
5. In the RAID Info section, click **Unconfigure**, and then click **OK**.
6. After the packetstore disk is deleted, click **Attach** and then click **OK**.
The extended storage unit is automatically configured and ready to store packets.

Reset Packetstore

In certain circumstances, you might want to reset the packetstore. For example, if you accidentally collected packets with sensitive data or from the wrong data feed, you can reset the datastore so the packets do not appear in any packet queries.

 **Warning:** If you reset the packetstore, all existing packets will be inaccessible to packet queries.

1. In the Appliance Settings section, click **Reset Packetstore**.
2. Type **YES** in the confirmation field and then click **Reset Packetstore**.

It typically takes less than a minute to reset the packetstore.

Trace Cluster Settings

The Trace Cluster Settings section includes the following sections:

Connect to RevealX 360

This option only appears when the packetstore is licensed for RevealX 360.

Manager

Enable a console to remotely run support scripts and upgrade firmware on the packetstore.

View the hostname of the console that is configured to manage the packetstore as well as a list of all sensors and consoles connected to the packetstore.

Packet Query Status

View a list of all packet queries generated from a connected console and connected sensors.

Manager

The Manager page contains the following information and controls:

Manager

Displays the hostname of the console that is configured to manage the packetstore. To connect a console through a tunneled connection, click **Manage with a Command Appliance**. A tunneled connection might be required if a direct connection cannot be established through the Command appliance.

Click **Remove Manager** to remove the console as the manager.



Note: The packetstore can be managed by only one console.

Connected Appliances

Displays a table of all sensors and consoles connected to the packetstore. The table includes the hostname, product key and IP address of the connected ExtraHop system.

Packet Query Status

The Packet Query Status page provides a collection of metrics about the packetstore.

The metrics on this page can help you troubleshoot problems and determine why the packetstore is not performing as expected.

Packet Query Status

Displays statistics about packet queries run from the Packets page.

If the number of simultaneous packet queries exceeds the maximum allotted system memory, errors might occur and you must delete in-progress or completed queries by clicking the **Remove** or **Remove All** button before you can create new queries. Queries are cached until you navigate away from the Packets page.

Packetstore Disks

Displays statistics about packet storage disks.

SSL Session Key Storage

Displays statistics about session keys stored on the packetstore. For information about session key storage, see [Store TLS session keys on connected packetstores](#).

Remove packet queries

You can remove one or more packet queries to clear query memory and disk cache.

1. In the Trace Cluster Settings section, click **Packet Query Status**.
2. Do one of the following:
 - To remove a single query, click **Remove** in the Actions column of the query you want to remove.
 - To remove all listed queries, click **Remove All**.

Manage with a console

Connect the packetstore to a console to remotely run support scripts and upgrade firmware on the packetstore from the console.

The packetstore connects to the console through a tunneled connection. Tunneled connections are required in network environments where a direct connection from the console is not possible because of firewalls or other network restrictions.

Before you begin



Note: This procedure only enables you to perform management functions from a connected console or RevealX 360. To search and download packets from the ExtraHop system, follow the instructions in [Connect sensors and console to the packetstore](#).

1. In the Trace Cluster Settings section, click **Manager**.
2. Click **Manage with Command Appliance**.
3. Configure the following settings:
 - Command appliance hostname : Type the hostname or IP address of the console.
 - Command appliance setup password : Type the `setup` user password for the console.
 - Trace appliance nickname : Type a friendly name for the ExtraHop packetstore. If no nickname is entered, the node is identified by the hostname.
4. Select the Manage with Command appliance checkbox and then click **Manage**.