


# Save system settings to the running config file

Published: 2018-11-09

When you modify any of the system configuration settings on an ExtraHop appliance, you must confirm the updates by saving the running config file. If you do not save the settings, those changes are lost when your ExtraHop appliance is rebooted.

When the running configuration has changed, the ExtraHop Admin UI displays a **View and Save Changes** button to remind you to save changes to disk. In addition, a red asterisk appears next to the **Running Config** link on the main Admin UI page and next to the **Save config** link on the Running Config page.



The screenshot shows the ExtraHop Admin UI. At the top left is the ExtraHop logo with the tagline "Discover". To its right is a search bar. Below the logo and search bar is a breadcrumb trail: "Admin > Connectivity". A notification banner states "Running config has changed" followed by a blue button labeled "View and Save Changes". Below the notification is the "Connectivity" section, which is divided into two tabs: "Network Settings" and "Proxy Settings". Under "Network Settings", the "Hostname" field is visible with the value "example-eda". Under "Proxy Settings", there is a link labeled "Enable Global Proxy".

To save any modified system configuration settings, complete the following steps.

1. Click **View and Save Changes**.
2. Review the comparison between the old running config and the current running config (not yet saved).
3. If the changes are correct, click **Save**. Otherwise, click **Cancel**, and if necessary, revert the changes by clicking **Revert config**.