

# Discover and Command Post-deployment Checklist

---

Published: 2019-07-15

After you deploy the ExtraHop Discover or Command appliance, log into the Admin UI and configure the following settings. Refer to the section of the [ExtraHop Admin UI Guide](#) specified in each action below, except where noted.

## Password

Maintain system security after the evaluation period. Change the default password. For more information, see the [Default User Accounts FAQ](#).

## NTP

Time is critical in the ExtraHop appliance, particularly when doing event correlation with time-based metrics and logs. Verify that the NTP settings are correct for your infrastructure, test settings, and sync NTP. For more information, see [Configure the system time](#).

## Time Zone

The correct time zone is critical to run scheduled reports at the correct time. Ensure the ExtraHop appliance has the correct time zone. For more information, see [Configure the system time](#).

## Remote Authentication

Set up remote authentication. The ExtraHop appliance integrates with [LDAP](#), [RADIUS](#), and [TACACS+](#) for remote integration.

## Firmware Update

The ExtraHop appliance firmware is updated often with enhancements and resolved defects. Verify that you have the current firmware. For more information, see [Upgrade the firmware on your ExtraHop appliance](#).

## Audit Logging

The ExtraHop appliance can send events to a remote syslog collector. For more information, see the [Send audit log data to a remote syslog server](#).

## SMTP

The ExtraHop appliance can email alerts and system-health notifications. Set up and test notifications. For more information, see [Configure email settings for notifications](#).

## System Notifications

The ExtraHop appliance can send email when it detects problems. Create an email group to receive notifications. For more information, see [Configure an email notification group on a Discover or Command appliance](#).

## iDRAC

Each physical ExtraHop appliance has an iDRAC port, similar to iLO or KVM over Ethernet. Connect and configure the iDRAC port. For more information, see [Configure the iDRAC Remote Access Console](#).

## SSL Certificate

Each ExtraHop appliance ships with a self-signed certificate. If you have a PKI deployment, generate your own certificate and upload it to each ExtraHop appliance. For more information, see the [SSL Certificate](#) section in the Admin UI Guide.

## DNS A Record

It is easier to access an ExtraHop appliance by hostname than by IP address. Create an A record in your DNS root ("exa.yourdomain.local") for each ExtraHop appliance in your deployment. Refer to your DNS administration manual.

## Connect Appliances

Connect Command and Discover appliances to all Explore and Trace appliances. For more information, see [Connect the Discover and Command appliances to Explore appliances](#) and [Connect the Discover and Command appliances to the Trace appliance](#).

## Cloud Services

Connect to ExtraHop Cloud Services to enable Detections and Remote Access. For more information, see [Connect to ExtraHop Cloud Services](#).

## Threat Intelligence

Configure threat intelligence settings to help detect malicious attacks on your network. For more information, see [Threat intelligence](#).

## Network Localities

Classify non-RFC1918 IP addresses as part of your internal network. For more information, see [Specify the locality for IP addresses](#).

## Custom Parameters

Help improve the quality and accuracy of rules-based detections by adding custom parameters. For more information, see [Specify custom parameters](#).

## Advanced Analysis

Target specific device groups or activity groups for Advanced Analysis as needed, based on their importance to your network. For more information, see [Analysis priorities](#).

## Decrypt SSL Traffic

Decrypt forwarded SSL traffic by uploading the private key and server certificate associated with that traffic. For more information, see [Decrypt SSL traffic with certificates and private keys](#).

## Configure Perfect Forward Secrecy (PFS)

Decrypt SSL/TLS traffic from your Linux and Windows servers. For more information, see [Install the ExtraHop session key forwarder on a Linux server](#) and [Install the ExtraHop session key forwarder on a Windows server](#).

## Customizations and Datastore Backup

Create a system backup prior to upgrading firmware, or before making a major change in your environment. For more information, see [Back up a Discover or Command appliance](#).