


# Deploy the ExtraHop Explore Appliance with VMware

Published: 2018-02-06

The following procedure guides you through the deployment process of the ExtraHop Explore virtual appliance with the vSphere client running on a Windows machine. You should be familiar with administrating VMware ESX and ESXi environments before proceeding.

The Explore virtual appliance is distributed as an OVA package that includes a preconfigured virtual machine (VM) with a 64-bit, Linux-based OS that is optimized to work with VMware ESX and ESXi version 5.0 and later.


 **Important:** If you want to deploy more than one ExtraHop virtual appliance, do not clone an existing instance. Always start with the original deployment package when deploying additional instances.

## System requirements

Your environment must meet the following requirements to deploy a virtual Explore appliance:

- An existing installation of VMware ESX or ESXi server version 5.0 and later capable of hosting the Explore virtual appliance. The Explore virtual appliance is available in the following configurations:

EXA-XS	EXA-S	EXA-M	EXA-L
4 CPUs	8 CPUs	16 CPUs	32 CPUs
8GB RAM	16 GB RAM	32 GB RAM	64 GB RAM
4 GB boot disk	4 GB boot disk	4 GB boot disk	4 GB boot disk
500 GB or smaller datastore disk	1.2 TB or smaller datastore disk	2.5 TB or smaller datastore disk	4.1 TB or smaller datastore disk

 **Note:** When you deploy an Explore appliance, a second virtual disk is required to store record data. The EXA-XS is preconfigured with a 500 GB datastore disk; however, you must manually add a second virtual disk to the other available EXA configurations. The minimum datastore disk size for all configurations is 150 GB.

Consult with your ExtraHop sales representative or Technical Support to determine the datastore disk size that is best for your needs.

- A vSphere client
- An Explore virtual appliance license key.
- The following TCP ports must be open:
  - TCP ports 80 and 443: Enables you to administer the Explore appliance through the Web UI. Requests sent to port 80 are automatically redirected to HTTPS port 443.
  - TCP port 9443: Enables Explore nodes to communicate with other Explore nodes in the same cluster.

## Deploy the Explore virtual appliance

To deploy the Explore virtual appliance, complete the following steps:

- Contact ExtraHop Support (support@extrahop.com) to obtain and download the OVA package.
- Start the VMware vSphere client and connect to your ESX server.

3. Go to the File menu and select **Deploy OVF Template**.
4. The steps to deploy the OVF template are described in detail below. For most deployments, the default settings are sufficient.
  - a) Source: Browse to the location of the downloaded OVA file and then click **Next**.
  - b) OVF Template Details: Review the details and then click **Next**.
  - c) Name and Location: Configure the VM name and location. Give the VM a unique and specific name for the ESX Inventory and then click **Next**.
  - d) Disk Format: Select **Thick Provision Lazy Zeroed** and then click **Next**.
  - e) Network Mapping: Map the OVF-configured network interface labels with the correct ESX-configured interface labels and then click **Next**.
  - f) Ready to Complete: Verify the configuration, do not select the Power on after deployment checkbox, and then click **Finish** to complete the deployment.

When the deployment is complete, you can see the unique name you assigned to the Explore appliance VM instance in the inventory tree for the ESX server to which it was deployed.

5. Click the new Explore appliance VM instance in the directory tree.
6. From the Actions drop-down list, select **Edit Settings...** to configure the disk where the Explore appliance data is stored.
7. From the New device drop-down list, select **New Hard Disk**, and then click **Add**.
8. In the New Hard disk field, type the size of your virtual storage disk and then click **OK**.
9. From the Actions drop-down list, select **Power On**.
10. From the Actions drop-down list, select **Open Console**.
11. Log in with the `shell` user account. Type `default` for the password.
12. Run the `show ipaddr` command to display the IP address of the Explore virtual appliance.
13. Exit the console window.

## (Optional) Configure a static IP address

The ExtraHop virtual appliance is delivered with DHCP enabled. If your network does not support DHCP, no IP address is acquired, and you must configure a static address manually. To configure a static IP address, complete the following steps:

1. Log in to the console with the `shell` user account. At the password prompt, type `default`, and then press ENTER.
2. To configure the static IP address, run the following commands:
  - a) Enable privileged commands:

```
enable
```

- b) At the password prompt, type `default`, and then press ENTER.
- c) Enter configuration mode:

```
configure
```

- d) Enter the interface configuration mode:

```
interface
```

- e) Run the `ip` command and specify the IP address and DNS settings in the following format: `ip ipaddr <ip_address> <netmask> <gateway> <dns_server>`

For example:

```
ip ipaddr 10.10.2.14 255.255.0.0 10.10.1.253 10.10.1.254
```

- f) Leave the interface configuration section:

```
exit
```

- g) Save the running config file:

```
running_config save
```

- h) Type `y` and then press ENTER.

## Configure the Explore appliance

After you obtain the IP address for the Explore appliance, log into the Explore Admin UI through the following URL: `https://<explore_ip_address>/admin` and complete the following recommended procedures.



**Note:** The default log in name is `setup` and the password is `default`.


- [Register an ExtraHop appliance](#)
- [Create an Explore cluster](#)
- [Configure the system time](#)
- [Configure email notifications](#)
- [Pair the Explore appliance to all Discover and Command appliances](#)
- [Send record data to the Explore appliance](#)

## Register the ExtraHop appliance

Complete the following steps to apply a product key supplied by ExtraHop Support.

If you do not have a product key, contact [support@extrahop.com](mailto:support@extrahop.com).

1. In your browser, type the IP address of the ExtraHop appliance (`https://<extrahop_ip_address>/admin`).
2. Review the license agreement, select **I Agree**, and then click **Submit**.
3. On the login screen, type `setup` for the username.
4. For the password, select from the following options:
  - For a physical appliance, type the service tag number found on the pullout tab on the front of the appliance.
 




**Note:** The serial number for the EDA 1100 is located on the bottom of the appliance, and displayed in the `Appliance info` section of the LCD menu.
  - For a virtual appliance, type `default`.
5. Click **Log In**.
6. In the System Settings section, click **License**.
7. Click **Manage License**.
8. Click **Register**.
9. Enter the product key and then click **Register**.
10. Click **Done**.

## Create an Explore cluster

### Before you begin

Log into the Admin UI of each Explore node, click **Fingerprint** in the Status section, and note the value listed in the Fingerprint field. The fingerprint of each node should be verified during the join process.

If you are deploying three or more Explore nodes, join the nodes to create a cluster.

 **Important:** Each node that you join must have the same configuration (physical or virtual) and ExtraHop firmware version.

1. Log into the Admin UI of any new Explore node.
2. In the Cluster Settings section, click **Join Cluster**.
3. In the Host text box, type the hostname or IP address of any of the other new nodes and then click **Continue**.
4. Verify that the fingerprint displayed on the page matches the fingerprint of the Explore node that you are joining. If these fingerprints do not match, communication between the nodes might have been intercepted and altered.
5. In the Setup Password field, type the password for the `setup` user.
6. Click **Join**.
7. In the Status section, click **Cluster Status**.
8. Wait for the Status field to change to `green`.
9. Repeat steps 1 - 8 to join each additional node to the new cluster.



**Note:** Always join a new node to the existing cluster and not another unjoined node, or you will create multiple clusters.

10. Click **Cluster Members** in the Cluster Settings section to confirm that all of the nodes are listed on the page.

## Configure the system time

By default, the Explore appliance synchronizes the system time through the `pool.ntp.org` network time protocol (NTP) server. If your network environment prevents the Explore appliance from communicating with this time server, you must configure an alternate time server source.



**Note:** Time synchronization is critical to ensuring proper cluster operations and maintaining consistent views of data across both Discover and Explore appliances. We strongly recommend that you either keep the default system time setting or configure settings for a different NTP server.

1. In the System Settings section, click **System Time**.
2. Click **Configure Time**.
3. Click the Time Zone drop-down list and select a time zone. Click **Save and Continue**.
4. Select the Use NTP server to set time radio button and then click **Select**.
5. Type the IP addresses for the time server, and then click **Save**.
6. Click **Done**.
7. Click **Sync Now** to sync system time on the Explore appliance with the remote time server.

## Configure email notifications

You must configure an email server and sender before the ExtraHop appliance can send notifications about system alerts by email.

You can receive the following alerts from the system:

- A virtual disk is in a degraded state.
- A physical disk is in a degraded state.
- A physical disk has an increasing error count.
- A registered Explore node is missing from the cluster. The node might have failed, or is powered off.

## Pair the Explore appliance to Discover and Command appliances




After you deploy the Explore cluster, you must establish a connection from all ExtraHop Discover and Command appliances to the Explore cluster before you can query records. If you manage all of your

Discover appliances from a Command appliance, you only need to perform this procedure from the Command appliance.

1. Log into the Discover or Command appliance Admin UI.
2. In the ExtraHop Explore Settings section, click **Configure Explore Cluster**.
3. Click **Add New**.
4. In the Host #1 Host field, type the hostname or IP address of any Explore appliance in the Explore cluster.
5. For each additional Explore appliance in the cluster, click **Add New** and enter the individual hostname or IP address in the corresponding Host field.
6. Click **Save**.
7. Note the information listed for Fingerprint. Verify that the fingerprint listed on this page matches the fingerprint of the Explore appliance (**Host #1**) listed on the Fingerprint page in the Explore Admin UI.
8. In the Explore Setup Password field, type the password of the Explore appliance.
9. Click **Join**, and then click **Done**.

### Send record data to the Explore appliance

After your Explore appliance is paired with all of your Discover and Command appliances, you must configure the type of records you want to store. See the following documentation for more information about Explore configuration settings, how to generate and store records, and how to create record queries.

- [ExtraHop Explore Admin UI Guide](#) 
- [ExtraHop Explore Settings](#)  section in the *ExtraHop Admin UI Guide*.
- [Records](#)  section in the *ExtraHop Web UI Guide*.
- [ExtraHop Trigger API Reference](#) 