

# Deploy the ExtraHop Command Appliance on Linux KVM

Published: 2020-05-15

This document provides information on how to install the ExtraHop Command virtual appliance on a Linux kernel-based virtual machine (KVM). This guide assumes that you are familiar with basic KVM administration.

If you have not already done so, download the ExtraHop Command virtual appliance file for KVM from the [ExtraHop Customer Portal](#).

**Important:** If you want to deploy more than one ExtraHop virtual appliance, create the new instance with the original deployment package or clone an existing instance that has never been started.

## Requirements

Before you can install the ExtraHop virtual appliance, make sure that your environment meets the following requirements:

- A KVM hypervisor environment capable of hosting a VM that has:
  - 4 GB RAM
  - Two vCPUs
  - One 4 GB boot disk (virtio-scsi interface recommended)
  - One 40 GB datastore disk (virtio-scsi interface recommended)
- An ExtraHop virtual appliance license key

## Performance guidelines

The following table provides guidelines that can help you optimize the performance of the Command appliance. These guidelines are minimum requirements that you might need to adjust based on the size and needs of your environment.

Scalability	Connected ExtraHop Appliances	1-8	9-24	25-64
Provisioning Requirements	CPU Cores	4	8	16
	RAM	8 GB	16 GB	32 GB
	Boot Disk	4 GB	4 GB	4 GB
	Datastore and Utility Disk	40 GB	48 GB	64 GB
	Disk Total	44 GB	52 GB	68 GB

## Package contents

The installation package for KVM systems is a `tar.gz` file that contains the following items:

### `eca.xml`

The domain XML configuration file

#### **eca.xml.md5**

An MD5 checksum file to verify the integrity of the eca.xml file.

#### **extrahop-boot.qcow2**

The boot disk

#### **extrahop-boot.qcow2.md5**

An MD5 checksum file to verify the integrity of the extrahop-boot.qcow2 file.

#### **extrahop-data.qcow2**

The datastore disk

#### **extrahop-data.qcow2.md5**

An MD5 checksum file to verify the integrity of the extrahop-data.qcow2 file.

## Edit the domain XML configuration file

Edit the configuration file and create the ExtraHop virtual appliance.

1. Extract the `tar.gz` file that contains the installation package.
2. Copy the two disks `extrahop-boot.qcow2` and `extrahop-data.qcow2` to your KVM system. Make a note of the location where you store these files.
3. Open the domain XML configuration file. Find and edit the following values:
  - a) Change the VM name (`ExtraHop-ECA`) to the name you want to assign to your ExtraHop virtual appliance.

```
<name>ExtraHop-ECA</name>
```

- b) Change the source file path `[PATH_TO_STORAGE]` with the location where you stored the virtual disk files in step 1.

```
<source file=' [PATH_TO_STORAGE] /extrahop-boot.qcow2' />
<source file=' [PATH_TO_STORAGE] /extrahop-data.qcow2' />
```

4. Save the XML file.
5. Log in to the KVM console.
6. Create the new ExtraHop virtual appliance with your revised domain XML configuration file by running the following command:

```
virsh define eca.xml
```

7. Start the virtual machine by running the following command:

```
virsh start <vm_name>
```

Where `<vm_name>` is the name of your virtual appliance you configured in step 3.

## (Optional) Configure a static IP address

By default, ExtraHop appliances ship with DHCP enabled. If your network does not support DHCP, you must configure a static address manually.

1. Log in to the KVM host.
2. Run the following command to connect to the ExtraHop system through the virtual serial console:

```
virsh console <vm_name>
```

Where `<vm_name>` is the name of your virtual machine.

3. Press ENTER twice to get to the appliance login prompt.

```
ExtraHop Discover Appliance Version 7.8.2.2116
IP: 192.0.2.81
exampleium login:
```

4. At the login prompt, type `shell`, and then press ENTER.
5. At the password prompt, type `default`, and then press ENTER.
6. To configure the static IP address, run the following commands:
  - a) Enable privileged commands:

```
enable
```

- b) At the password prompt, type `default`, and then press ENTER.
  - c) Enter configuration mode:

```
configure
```

- d) Enter the interface configuration mode:

```
interface
```

- e) Run the `ip` command and specify the IP address and DNS settings in the following format: `ip ipaddr <ip_address> <netmask> <gateway> <dns_server>`  
For example:

```
ip ipaddr 10.10.2.14 255.255.0.0 10.10.1.253 10.10.1.254
```

- f) Leave the interface configuration section:

```
exit
```

- g) Save the running config file:

```
running_config save
```

- h) Type `y` and then press ENTER.

## Post-deployment actions

Open a web browser and type the IP address of the Command appliance in the address bar and then press **ENTER**. Accept the EULA and enter the product key to license the appliance.

Log in to the ExtraHop system with the `setup` user account and type `default` for the password.

- Review the [Discover and Command Post-deployment Checklist](#) and configure additional Command settings.
- [Connect a Command appliance to Discover appliances](#)
- [Connect the Discover and Command appliances to Explore appliances](#)
- [Connect the Discover and Command appliances to the Trace appliance](#)