Create a recordstore cluster

Published: 2024-04-01

For the best performance, data redundancy, and stability, you must configure at least three recordstores in a cluster.

() Important: If you are creating a recordstore cluster with six or more nodes, you must configure the cluster with manager nodes. For manager node instructions, see Deploying manager nodes ^I.

In the following example, the recordstores have the following IP addresses:

- Node 1: 10.20.227.177
- Node 2: 10.20.227.178
- Node 3: 10.20.227.179

You will join nodes 2 and 3 to node 1 to create the recordstore cluster. All three nodes are data nodes. You cannot join a data node to a manager node or join a manager node to a data node to create a cluster.

() Important: Each node that you join must have the same configuration (physical or virtual) and the same ExtraHop firmware version. EXA 5100 and EXA 5200 physical recordstores can be in the same cluster.

Before you begin

You must have already installed or provisioned the recordstores in your environment before proceeding.

- 1. Log in to the Administration settings on all three recordstores with the setup user account in three separate browser windows or tabs.
- 2. Select the browser window of node 1.
- 3. In the Status and Diagnostics section, click **Fingerprint** and note the fingerprint value. You will later confirm that the fingerprint for node 1 matches when you join the remaining two nodes.
- 4. Select the browser window of node 2.
- 5. In the Explore Cluster Settings section, click **Join Cluster**.
- 6. In the Host field, type the hostname or IP address of data node 1 and then click **Continue**.

Note: For cloud-based deployments, be sure to type the IP address listed in the Interfaces table on the Connectivity page.

7. Confirm that the fingerprint on this page matches the fingerprint you noted in step 3.

🕶 ExtraHop

| • • • 10.20 | .227.177 - ExtraHop Admi 🗙 🖙 10.20.227.178 - Cluster Membe 🗙 🐄 ExtraHop - Join |
|--|--|
| \leftrightarrow \Rightarrow C \blacktriangle Not | Secure https://10.20.227.219/admin/exa/join/2 |
| ExtraH | OP Welcor |
| Admin - Join Cluster | |
| | |
| Host: | 10.20.227.177 |
| Fingerprint: | 0C:CF:FA:2D:93:D2:66:20:87:08:79:07:AE:A6:8E:26:61:82:29:0C:BC:7E:29:55:24:17:C9 |
| Version: | 7.4.0.1357 |
| Setup Password: | |
| | |

- 8. In the Setup Password field, type the password for the node 1 setup user account and then click Join. When the join is complete, the Explore Cluster Settings section has two new entries: Cluster Members and Cluster Data Management.
- 9. Click Cluster Members. You should see node 1 and node 2 in the list.

| C A Not Secure | https://10.20.227 | 178/admin/exa/nodes/ | | |
|--|-------------------|--------------------------------|---------------------------|------|
| | | | | Welc |
| | | | | |
| Admin -> Cluster Members | | | | |
| Admin - Cluster Members Cluster Mem Nickname | bers Host | Firmware Version | License Status | Co |
| Cluster Mem | | Firmware Version 7.4.0.1357 | License Status Nominal | C |

- 10. In the Status and Diagnostics section, click **Explore Cluster Status**. Wait for the Status field to change to Green before adding the next node.
- 11. Repeat steps 5 10 to join each additional node to the new cluster.

10.20.227.178

Note: To avoid creating multiple clusters, always join a new node to an existing cluster and not to another single appliance.

12. When you have added all of your recordstores to the cluster, click **Cluster Members** in the Explore Cluster Settings section. You should see all of the joined nodes in the list, similar to the following figure.

| • • • / • 10.20.227. | 🔍 🔍 👘 10.20.227.177 - ExtraHop Admi 🗙 😒 10.20.227.178 - Connectivity - 🗙 😒 10.20.227.179 - Cluster Membi 🛪 | | | | | | | | |
|---|--|------------------|----------------|------------------------|-----------------------------------|------|--|--|--|
| ← → C ▲ Not Secure https://10.20.227.219/admin/exa/nodes/ | | | | | | | | | |
| ExtraHop | | | | Welcome, setup. Change | e default password Log Out H | lelp | | | |
| Admin + Cluster Members | | | | Hostname: 10.20.227.2 | 19 SID: EXTR-EXTR Version: 7.4.0. | 1357 | | | |
| Cluster Members | | | | | | | | | |
| Nickname | Host | Firmware Version | License Status | Connection Status | Actions | | | | |
| 10.20.227.177 | 10.20.227.177 | 7.4.0.1357 | Nominal | Connected | Remove Node | | | | |

Nominal

Nominal

Connected

Connected

13. In the Explore Cluster Settings section, click **Cluster Data Management** and make sure that **Replication Level** is set to **1** and **Shard Reallocation** is **ON**.

7.4.0.1357

7.4.0.1357

Next steps

10.20.227.178

10.20.227.179 (this node) 10.20.227.179

Remove Node

Leave Explore Cluster

🍯 ExtraHop

Connect the console and sensors to ExtraHop recordstores 🗷