

Download the running configuration as a text file

Published: 2024-03-26

You can download the running configuration file to your workstation. You can open this text file and make changes to it locally, before copying those changes into the Running Config window.

1. Click **Running Config**.
2. Click **Download config as a File**.

The current running configuration file is downloaded as a text file to your default download location.