

Safety information for the ExtraHop Discover 1200 appliance

Published: 2021-08-28

This document provides safety compliance information for the ExtraHop Discover 1200 appliance.

Safe use and installation instructions

1. Do not open or modify the device. The device has been tested and complies with FCC and CE regulations. Modification of the device will void these certifications.
2. Install the device securely. Be careful handling the device to prevent injury and do not drop.
3. Operational temperature must be between 0-40° C with a relative, non-condensing humidity of 0-90%. The device can be stored at temperatures between 0-60° C.
4. Keep the device away from liquids and flammable materials.
5. Do not clean the device with liquids. The chassis can be cleaned with a cloth.
6. Allow at least 2 inches of space around all sides of the device for proper cooling.
7. This device is intended for indoor operation only.
8. Install this device only with the supplied AC power adapter. Ensure proper voltage and current ratings of the power supply.
9. Install the device only with shielded network cables.
10. Install molded ferrite filtered DisplayPort cables only, such as Monoprice P/N 12001 or equivalent.
11. Service and repair of the device must be done by qualified service personnel.



Warning: There is danger of explosion if the CMOS battery is replaced incorrectly.